

# DECUS

## PROGRAM LIBRARY

DECUS NO.	8-602B
TITLE	THE PDP-8 COOKBOOK, VOLUME 2
AUTHOR	Floor Anthoni
COMPANY	Medical Biological Laboratory TNO Rijswijk, The Netherlands
DATE	May 1, 1973
SOURCE LANGUAGE	PAL III, PAL-D, PAL-8

### ATTENTION

This is a USER program. Other than requiring that it conform to submittal and review standards, no quality control has been imposed upon this program by DECUS.

The DECUS Program Library is a clearing house only; it does not generate or test programs. No warranty, express or implied, is made by the contributor, Digital Equipment Computer Users Society or Digital Equipment Corporation as to the accuracy or functioning of the program or related material, and no responsibility is assumed by these parties in connection therewith.

THE PDP-8 COOKBOOK, VOLUME 2

DECUS Program Library Write-up

DECUS NO. 8-602B

THIS VOLUME IS ISSUED IN THREE PARTS:

PART 1 CONTAINS A DIRECTORY OF ALL SUBROUTINE NAMES.  
A DIRECTORY, SELECTED BY FUNCTIONAL KEYWORDS.  
NAMES AND CONTRIBUTIONS OF AUTHORS.  
DEFINITIONS OF KEYWORDS IN USE.

PART 2 CONTAINS REVISIONS TO SUBROUTINES IN VOLUME #1.

PART 3 CONTAINS 44 NEW PROGRAM MODULES.

AUTHORS OF THE PDP8 COOKBOOK AND THEIR CONTRIBUTIONS

=====

FLOOR ANTHONI  
MEDICAL BIOLOGICAL LABORATORY T. N. O.  
LANGE KLEIWEG 139; RIJSWIJK (ZH); THE NETHERLANDS

1, 2, 3, 4, 5, 6, 7, 9, 10, 11, 12, 13, 14, 15, 17, 18, 49, 50, 51, 52, 53, 54,  
55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72

ANDRIES E. BROUWER  
MATHEMATISCH CENTRUM  
2DE BOERHAAVESTRAAT 49; AMSTERDAM

80, 81, 13, 12B

THIERRI DEN DUNNEN  
DR. NEHER LABORATORIUM  
ST. PAULUSSTRAAT 4; LEIDSCHENDAM; THE NETHERLANDS

19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37,  
38, 39, 73, 74, 75, 76, 77, 78, 79, 13, 12A, 10

ADRI. HEMELAAR  
MEDICAL BIOLOGICAL LABORATORY T. N. O.  
LANGE KLEIWEG 139; RIJSWIJK (ZH); THE NETHERLANDS

45, 46, 47, 48, 82, 83

PAUL LOHMAN  
MEDICAL BIOLOGICAL LABORATORY T. N. O.  
LANGE KLEIWEG 139; RIJSWIJK (ZH); THE NETHERLANDS

16

HANS MEES  
MEDICAL BIOLOGICAL LABORATORY T. N. O.  
LANGE KLEIWEG 139; RIJSWIJK (ZH); THE NETHERLANDS

8

C. VERWEY  
LABORATORIUM VOOR BIOLOGISCHE EN MEDISCHE NATUURKUNDE  
MEDISCHE FACULTEIT ERASMUS UNIVERSITEIT ROTTERDAM  
P. O. BOX 1738; ROTTERDAM; THE NETHERLANDS

40, 41, 42, 43, 44

KEYWORDS, CURRENTLY USED IN THE FDP8 COOKBOOK

=====

FUNCTIONS

=====

- ARITHMETIC = ALL TYPES OF OPERATIONS OF AN ARITHMETIC NATURE (+-\* /ETC. BUT ALSO BOOLEAN ALGEBRA)
- STRINGS = USED TO DENOTE ALL TYPES OF OPERATIONS RELATED TO THE ORGANISATION AND STRUCTURE OF DATA. (ALSO: BUFFERS, CONVENTIONAL 'STRINGS' ETC.)
- FILE = OPERATIONS THAT ORGANIZE A DATA STRUCTURE ON A LARGE STORAGE, BACKING UP DEVICE.
- SORTING = USED TO DENOTE THE TYPE OF OPERATIONS WHERE THE COMPARISON OF DATA WITH OTHER DATA IS ESSENTIAL.
- CONVERSION = CONVERSION FROM ONE DATA STRUCTURE OR FORMAT TO ANOTHER.
- PROGRAM CONTROL = DENOTES OPERATIONS THAT ARE USED TO DIRECT THE FLOW OF THE PROGRAM IN THE FIRST INSTANCE.
- INPUT = OPERATIONS THAT INPUT DATA INTO THE COMPUTER.
- OUTPUT = OPERATIONS THAT PUT DATA OUT FROM THE COMPUTER.
- INTERRUPT = DENOTES OPERATIONS WHERE THE INTERRUPT IS USED.
- GRAPHICS = OPERATIONS ON GRAPHICAL DATA, AND DISPLAY
- SIGNAL PROCESSING = OPERATIONS OF A MATHEMATICAL NATURE ON DATA THAT REPRESENT SOME SIGNAL.

DATA FORMATS

=====

- BINARY = THE CONVENTIONAL 'BINARY' FORMAT AS IT IS USED BY LOADERS.
- ASCII = 8 BIT DATA, REPRESENTING ONE CHARACTER FOLLOWING THE USASCII STANDARD
- CODE = A CHARACTER REPRESENTATION FOLLOWING SOME OTHER STANDARD
- OCTAL = ASCII, RESTRICTED TO OCTAL VALUES
- DECIMAL = ASCII, RESTRICTED TO DECIMAL VALUES
- HEXADECIMAL = ASCII, RESTRICTED TO HEXADECIMAL VALUES.
- IMAGE = THE 12 BIT WORD AND SEQUENCES OF FDP8 COMPUTER WORDS.

SYSTEM SOFTWARE RESTRICTIONS

=====

- DISKMONITOR = CONFINED FOR DISK MONITOR USERS
- OS8 = CONFINED FOR OS8 USERS
- TSS8 = CONFINED FOR TSS8 TIMESHARING USERS

DEVICE TYPE RESTRICTIONS

=====

- DISK = DF32, RF08, RK08 ETC.
- DECTAPE = DIGITAL EQUIPMENT'S MAGNETIC TAPE UNITS
- MAGTAPE = INDUSTRIAL AND OTHER MAGNETIC TAPE DEVICES
- DISPLAY = ALL TYPES OF DISPLAYS, CHARACTER- AND VECTOR TYPES
- PAPERTAPE = PAPERTAPE READERS AND PUNCHES.

001 TYPE THE CHARACTERS FOLLOWING THE JMS INSTRUCTION.  
K: STRINGS, OUTPUT, ASCII

002 TELETYPE TYPE ROUTINE WITH OVERLAP; NOT RESTARTABLE.  
K: OUTPUT, ASCII, BINARY

003 TYPE A CHARACTER CHAIN  
K: OUTPUT, ASCII

004 DECIMAL TO DECIMAL CONVERSION AND TYPE  
K: OUTPUT, CONVERSION, BINARY, IMAGE

005 BINARY TO OCTAL CONVERSION AND PRINT  
K: OUTPUT, CONVERSION, OCTAL

006 HIGH SPEED READER SUBROUTINE  
K: OUTPUT, PAPERTAPE, ASCII, BINARY

007 TABULATOR ROUTINE  
K: STRINGS, ASCII, OUTPUT

008 SUBROUTINE TO MOVE A BLOCK THROUGH CORE  
K: SORTING, STRINGS, IMAGE

009 BINARY PUNCH WITH FIELD SETTING  
K: CONVERSION, IMAGE, BINARY, OUTPUT

010 PAL MESSAGE PRINTER  
K: OUTPUT, ASCII, CONVERSION,

011 GENERAL BRANCH ROUTINE  
K: PROGRAM CONTROL,

012 CHECK IF OCTAL  
K: PROGRAM CONTROL, OCTAL, ASCII

013 LOGICAL OPERATORS ON TWO NUMBERS  
K: ARITHMETIC

014 PSS-058 OPTION DECODER  
K: PROGRAM CONTROL, 058

015 PRINT TWO DIGITS IN DECIMAL  
K: OUTPUT, DECIMAL, CONVERSION

016 PRINT THE PSS-058 DATE  
K: OUTPUT, 058, DECIMAL

017 PRINT THE AC AS A FOCAL LINENUMBER  
K: OUTPUT, CONVERSION, DECIMAL

018 PRINT 4 DECIMAL DIGITS USING ROUTINE PRNT2  
K: OUTPUT, CONVERSION, DECIMAL

019 SUBROUTINE READS A DECIMAL NUMBER FROM KEYBOARD  
K: INPUT, CONVERSION, DECIMAL

020 DECIMAL PRINT ROUTINE  
K: OUTPUT, CONVERSION, DECIMAL

021 SUBROUTINE TO PRINT DOUBLE LENGTH DECIMAL  
K: OUTPUT, CONVERSION, DECIMAL

022 OCTAL PRINT ROUTINE  
K: OUTPUT, CONVERSION, OCTAL

023 DOUBLE WORD OCTAL PRINT ROUTINE, USES OCTPRT  
K: OUTPUT, CONVERSION, OCTAL

024 SUBROUTINE TRANSLATES TELEX CODE TO ASCII  
K: CONVERSION, TELEX, ASCII

025 SUBROUTINE TO TRANSLATE TELEX CODE TO ASCII  
K: CONVERSION, ASCII, CODE

026 ROUTINE TO TRANSLATE ASCII TO TELEX CODE  
K: CONVERSION, ASCII, CODE

027 INTERRUPT OUTPUT HANDLER WITH ROTATING BUFFER  
K: INTERRUPT, STRINGS, OUTPUT, ASCII

028 DEVICE INTERRUPT HANDLER  
K: INTERRUPT, STRINGS, OUTPUT, ASCII

029 SUBROUTINE READS OR WRITES DECTAPE IN 2 DIRECTIONS  
K: INPUT, OUTPUT, DECTAPE, IMAGE, FILE

030 SUBROUTINE TO PACK CHARACTERS (TSS8)  
K: CONVERSION, STRINGS, ASCII, TSS8

031 SUBROUTINE PACKS CHARACTERS ONE BY ONE (TSS8 FORMAT)  
K: CONVERSION, STRINGS, ASCII, TSS8

032 SUBROUTINE TO PACK CHARACTERS ONE BY ONE (TSS8 FORMAT)  
K: CONVERSION, STRINGS, ASCII, TSS8

033 SUBROUTINE TO UNPACK CHARACTERS (TSS8 FORMAT)  
K: CONVERSION, STRINGS, ASCII, TSS8

034 SUBROUTINE UNPACKS CHARACTERS ONE BY ONE (TSS8 FORMAT)  
K: CONVERSION, STRINGS, ASCII, TSS8

035 SUBROUTINE TO READ A NAME FROM KEYBOARD (EXCESS 40 CODE)  
K: INPUT, CONVERSION, ASCII, STRINGS

036 SUBROUTINE SEARCHES NAME IN DN-BLOCKS (DISKMONITOR)  
K: FILE, STRINGS, DISKMONITOR, DECTAPE, DISK

037 SUBROUTINE SEARCHES UNUSED BLOCK ON DISK (DISKMONITOR)  
K: FILE, STRINGS, DISKMONITOR, DECTAPE, DISK

038 SUBROUTINE SEARCHES INTERNAL FILE NUMBER (DISKMONITOR)  
K: FILE, STRINGS, DISKMONITOR, DECTAPE, DISK

039 SUBROUTINE READS OR WRITES ON DISK (TSS8)  
K: FILE, INPUT, OUTPUT, DISK, TSS8

040 SUBROUTINE TO DISPLAY A BLOCK OF DATA ON VC8E  
K: CONVERSION, OUTPUT, DISPLAY, STRINGS

041 SUBROUTINE TO DISPLAY INPUT FROM AN ANALOG CHANNEL  
K: OUTPUT, CONVERSION, DISPLAY,

042 SUBROUTINE TO INPUT A BLOCK OF DIGITAL DATA (DR8E)  
K: INPUT, STRINGS

043 SUBROUTINE TO SMOOTH A BLOCK OF DATA IN MEMORY  
K: STRINGS, ARITHMETIC, SIGNAL PROCESSING

044 SUBROUTINE TO REDISTRIBUTE A BLOCK OF DATA  
K: STRINGS, ARITHMETIC, SIGNAL PROCESSING

045 PACK A CHARACTER IN A BUFFER IN OS8 FORMAT  
K: CONVERSION, STRINGS, ASCII, OS8

046 UNPACK A CHARACTER FROM A BUFFER IN OS8 FORMAT  
K: CONVERSION, STRINGS, ASCII, OS8

047 PARITY GENERATOR  
K: CONVERSION, ASCII

048 SKIP ON FLAG WITH TIMED OUT RETURN  
K: PROGRAM CONTROL, INPUT, OUTPUT

049 SEARCH A LIST FOR A MATCH  
K: STRINGS, PROGRAM CONTROL

050 LIST SEARCH, CROSS-FIELD CALLABLE  
K: PROGRAM CONTROL, STRINGS

051 RELATIVE BRANCHER, CROSS-FIELD CALLABLE  
K: PROGRAM CONTROL,

052 GENERAL SETUP FOR OS8 HANDLERS  
K: INPUT, OUTPUT, OS8, ASCII, BINARY

053 UNPACK CHAR-BY-CHAR FOR OS8 HANDLERS  
K: INPUT, STRINGS, OUTPUT, CONVERSION, ASCII, BINARY, OS8

054 UNPACK CHAR-BY-CHAR FOR OS8 HANDLERS  
K: INPUT, STRINGS, OUTPUT, CONVERSION, ASCII, BINARY, OS8

055 UNPACK AND PRINT OS8 BUFFER (DEVICE HANDLER)  
K: OUTPUTSTRINGS, CONVERSION, ASCII, BINARY, OS8

056 PUSH AND POP OPERATORS FOR DIFFERENT STACKS  
K: STRINGS, PROGRAM CONTROL

057 FILL A ROTATING BUFFER QUEUE (FIRST IN FIRST OUT)  
K: STRINGS

058 RESET (CLEAR) A ROTATING BUFFER QUEUE  
K: STRINGS

059 FETCH THE NEXT ITEM FROM THE HEAD OF THE QUEUE  
K: STRINGS

060 COMBINED ROTATING BUFFER OPERATORS, CROSS-FIELD CALLABLE  
K: STRINGS

061 BINARY LOADER SUBROUTINE  
K: INPUT, CONVERSION, BINARY, IMAGE

062 INTERRUPT SERVICE BY LIST-LOOK-UP  
K: INTERRUPT, PROGRAM CONTROL, INPUT, OUTPUT

063 FIND THE SMALLEST HOLE IN A LIST, JUST BIG ENOUGH  
K: STRINGS, SORTING

064 LINK FOR RELOCATABLE CROSS-PAGE REFERENCING IN ONE FIELD  
K: PROGRAM CONTROL

065 INITIALIZE THE FREECORE AREA  
K: STRINGS

066 REQUEST A FREE BLOCK  
K: STRINGS

067 RELEASE A BLOCK TO FREECORE  
K: STRINGS

068 RELEASE A QUEUE OF FORWARD LINKED BLOCKLETS TO FREECORE  
K: STRINGS

069 MAKE A BUFFER OR 'QUEUE'  
K: STRINGS

070 READ NEXT ELEMENT FROM THE TAIL OF A ROTATING BUFFER (QUEUE)  
K: STRINGS

071 WRITE AN ELEMENT ONTO THE TOP OF A BUFFERQUEUE  
K: STRINGS

072 KILL THE BUFFER QUEUE  
K: STRINGS

073 ROUTINE TO CONVERT OCTAL NUMBERS 0-17 TO EXCESS-40 STRIPPED CODE  
K: CONVERSION, OCTAL, CODE

074 INTERRUPT ROUTINE FOR REAL-TIME CLOCK  
K: INTERRUPT, CONVERSION

075 PRINT DATE, WEEKDAY AND TIME FROM THE REGISTERS.  
K: CONVERSION, DECIMAL

076 SUBROUTINE TO UNPACK TSS8 TIME  
K: CONVERSION, DECIMAL, TSS8

077 SUBROUTINE TO UNPACK TSS8 TIME  
K: CONVERSION, DECIMAL, TSS8



078 SUBROUTINE TO UNPACK TSS8 DATE.  
K: CONVERSION, DECIMAL, TSS8

079 DECIMAL PRINT WITH VARIABLE NUMBER OF DIGITS.  
K: OUTPUT, CONVERSION, DECIMAL

080 OCTAL PRINT WITH LEADING SPACES.  
K: OUTPUT, CONVERSION, OCTAL

081 DOUBLE WORD OCTAL PRINT ROUTINE  
K: OUTPUT, CONVERSION, OCTAL

082 ASCII STRING GENERATOR  
K: OUTPUT, ASCII, STRINGS

083 INCREMENT DOUBLE PRECISION COUNTER.  
K: ARITHMETIC

ARITHMETIC.

013 LOGICAL OPERATORS ON TWO NUMBERS  
043 SUBROUTINE TO SMOOTH A BLOCK OF DATA IN MEMORY  
044 SUBROUTINE TO REDISTRIBUTE A BLOCK OF DATA  
083 INCREMENT DOUBLE PRECISION COUNTER.

CONVERSION.

004 DECIMAL TO DECIMAL CONVERSION AND TYPE  
005 BINARY TO OCTAL CONVERSION AND PRINT  
009 BINARY PUNCH WITH FIELD SETTING  
010 PAL MESSAGE PRINTER  
015 PRINT TWO DIGITS IN DECIMAL  
017 PRINT THE AC AS A FOCAL LINENUMBER  
018 PRINT 4 DECIMAL DIGITS USING ROUTINE PRNT2  
019 SUBROUTINE READS A DECIMAL NUMBER FROM KEYBOARD  
020 DECIMAL PRINT ROUTINE  
021 SUBROUTINE TO PRINT DOUBLE LENGTH DECIMAL  
022 OCTAL PRINT ROUTINE  
023 DOUBLE WORD OCTAL PRINT ROUTINE, USES OCTPRT  
024 SUBROUTINE TRANSLATES TELEX CODE TO ASCII  
025 SUBROUTINE TO TRANSLATE TELEX CODE TO ASCII  
026 ROUTINE TO TRANSLATE ASCII TO TELEX CODE  
030 SUBROUTINE TO PACK CHARACTERS (TSS8)  
031 SUBROUTINE PACKS CHARACTERS ONE BY ONE (TSS8 FORMAT)  
032 SUBROUTINE TO PACK CHARACTERS ONE BY ONE (TSS8 FORMAT)  
033 SUBROUTINE TO UNPACK CHARACTERS (TSS8 FORMAT)  
034 SUBROUTINE UNPACKS CHARACTERS ONE BY ONE (TSS8 FORMAT)  
035 SUBROUTINE TO READ A NAME FROM KEYBOARD (EXCESS 40 CODE)  
040 SUBROUTINE TO DISPLAY A BLOCK OF DATA ON VC8E  
041 SUBROUTINE TO DISPLAY INPUT FROM AN ANALOG CHANNEL  
045 PACK A CHARACTER IN A BUFFER IN O88 FORMAT  
046 UNPACK A CHARACTER FROM A BUFFER IN O88 FORMAT  
047 PARITY GENERATOR  
053 UNPACK CHAR-BY-CHAR FOR O88 HANDLERS  
054 UNPACK CHAR-BY-CHAR FOR O88 HANDLERS  
055 UNPACK AND PRINT O88 BUFFER (DEVICE HANDLER)  
061 BINARY LOADER SUBROUTINE  
073 ROUTINE TO CONVERT OCTAL NUMBERS 0-17 TO EXCESS-40 STRIPPED CODE  
074 INTERRUPT ROUTINE FOR REAL-TIME CLOCK  
075 PRINT DATE, WEEKDAY AND TIME FROM THE REGISTERS.  
076 SUBROUTINE TO UNPACK TSS8 TIME  
077 SUBROUTINE TO UNPACK TSS8 TIME  
078 SUBROUTINE TO UNPACK TSS8 DATE.  
079 DECIMAL PRINT WITH VARIABLE NUMBER OF DIGITS.  
080 OCTAL PRINT WITH LEADING SPACES.  
081 DOUBLE WORD OCTAL PRINT ROUTINE

FILE,

029 SUBROUTINE READS OR WRITES DECTAPE IN 2 DIRECTIONS  
036 SUBROUTINE SEARCHES NAME IN DN-BLOCKS (DISKMONITOR)  
037 SUBROUTINE SEARCHES UNUSED BLOCK ON DISK (DISKMONITOR)  
038 SUBROUTINE SEARCHES INTERNAL FILE NUMBER (DISKMONITOR)  
039 SUBROUTINE READS OR WRITES ON DISK (TSS8)

INPUT,

019 SUBROUTINE READS A DECIMAL NUMBER FROM KEYBOARD  
029 SUBROUTINE READS OR WRITES DECTAPE IN 2 DIRECTIONS  
035 SUBROUTINE TO READ A NAME FROM KEYBOARD (EXCESS 40 CODE)  
039 SUBROUTINE READS OR WRITES ON DISK (TSS8)  
041 SUBROUTINE TO DISPLAY INPUT FROM AN ANALOG CHANNEL  
042 SUBROUTINE TO INPUT A BLOCK OF DIGITAL DATA (DR8E)  
048 SKIP ON FLAG WITH TIMED OUT RETURN  
052 GENERAL SETUP FOR OSS HANDLERS  
053 UNPACK CHAR-BY-CHAR FOR OSS HANDLERS  
054 UNPACK CHAR-BY-CHAR FOR OSS HANDLERS  
061 BINARY LOADER SUBROUTINE  
062 INTERRUPT SERVICE BY LIST-LOOK-UP

INTERRUPT,

027 INTERRUPT OUTPUT HANDLER WITH ROTATING BUFFER  
028 DEVICE INTERRUPT HANDLER  
062 INTERRUPT SERVICE BY LIST-LOOK-UP  
074 INTERRUPT ROUTINE FOR REAL-TIME CLOCK

SIGNAL PROCESSING,

043 SUBROUTINE TO SMOOTH A BLOCK OF DATA IN MEMORY  
044 SUBROUTINE TO REDISTRIBUTE A BLOCK OF DATA

SORTING,

008 SUBROUTINE TO MOVE A BLOCK THROUGH CORE  
063 FIND THE SMALLEST HOLE IN A LIST, JUST BIG ENOUGH

OUTPUT,

082 ASCII STRING GENERATOR  
001 TYPE THE CHARACTERS FOLLOWING THE JMS INSTRUCTION.  
002 TELETYPE TYPE ROUTINE WITH OVERLAP; NOT RESTARTABLE.  
003 TYPE A CHARACTER CHAIN  
004 DECIMAL TO DECIMAL CONVERSION AND TYPE  
005 BINARY TO OCTAL CONVERSION AND PRINT  
006 HIGH SPEED READER SUBROUTINE  
007 TABULATOR ROUTINE  
009 BINARY PUNCH WITH FIELD SETTING  
010 PAL MESSAGE PRINTER  
015 PRINT TWO DIGITS IN DECIMAL  
016 PRINT THE PS8-OS8 DATE  
017 PRINT THE AC AS A FOCAL LINENUMBER  
018 PRINT 4 DECIMAL DIGITS USING ROUTINE PRNT2  
020 DECIMAL PRINT ROUTINE  
021 SUBROUTINE TO PRINT DOUBLE LENGTH DECIMAL  
022 OCTAL PRINT ROUTINE  
023 DOUBLE WORD OCTAL PRINT ROUTINE, USES OCTPRT  
027 INTERRUPT OUTPUT HANDLER WITH ROTATING BUFFER  
028 DEVICE INTERRUPT HANDLER  
029 SUBROUTINE READS OR WRITES DECTAPE IN 2 DIRECTIONS  
039 SUBROUTINE READS OR WRITES ON DISK (TSS8)  
040 SUBROUTINE TO DISPLAY A BLOCK OF DATA ON VC8E  
041 SUBROUTINE TO DISPLAY INPUT FROM AN ANALOG CHANNEL  
048 SKIP ON FLAG WITH TIMED OUT RETURN  
052 GENERAL SETUP FOR OS8 HANDLERS  
053 UNPACK CHAR-BY-CHAR FOR OS8 HANDLERS  
054 UNPACK CHAR-BY-CHAR FOR OS8 HANDLERS  
055 UNPACK AND PRINT OS8 BUFFER (DEVICE HANDLER)  
062 INTERRUPT SERVICE BY LIST-LOOK-UP  
079 DECIMAL PRINT WITH VARIABLE NUMBER OF DIGITS.  
080 OCTAL PRINT WITH LEADING SPACES.  
081 DOUBLE WORD OCTAL PRINT ROUTINE  
082 ASCII STRING GENERATOR

PROGRAM CONTROL,

011 GENERAL BRANCH ROUTINE  
012 CHECK IF OCTAL  
014 PS8-OS8 OPTION DECODER  
048 SKIP ON FLAG WITH TIMED OUT RETURN  
049 SEARCH A LIST FOR A MATCH  
050 LIST SEARCH, CROSS-FIELD CALLABLE  
051 RELATIVE BRANCHER, CROSS-FIELD CALLABLE  
056 PUSH AND POP OPERATORS FOR DIFFERENT STACKS  
062 INTERRUPT SERVICE BY LIST-LOOK-UP  
064 LINK FOR RELOCATABLE CROSS-PAGE REFERENCING IN ONE FIELD

STRINGS.

082 ASCII STRING GENERATOR  
001 TYPE THE CHARACTERS FOLLOWING THE JMS INSTRUCTION.  
007 TABULATOR ROUTINE  
008 SUBROUTINE TO MOVE A BLOCK THROUGH CORE  
027 INTERRUPT OUTPUT HANDLER WITH ROTATING BUFFER  
028 DEVICE INTERRUPT HANDLER  
030 SUBROUTINE TO PACK CHARACTERS (TSS8)  
031 SUBROUTINE PACKS CHARACTERS ONE BY ONE (TSS8 FORMAT)  
032 SUBROUTINE TO PACK CHARACTERS ONE BY ONE (TSS8 FORMAT)  
033 SUBROUTINE TO UNPACK CHARACTERS (TSS8 FORMAT)  
034 SUBROUTINE UNPACKS CHARACTERS ONE BY ONE (TSS8 FORMAT)  
035 SUBROUTINE TO READ A NAME FROM KEYBOARD (EXCESS 40 CODE)  
036 SUBROUTINE SEARCHES NAME IN DN-BLOCKS (DISKMONITOR)  
037 SUBROUTINE SEARCHES UNUSED BLOCK ON DISK (DISKMONITOR)  
038 SUBROUTINE SEARCHES INTERNAL FILE NUMBER (DISKMONITOR)  
040 SUBROUTINE TO DISPLAY A BLOCK OF DATA ON VC&E  
042 SUBROUTINE TO INPUT A BLOCK OF DIGITAL DATA (DR&E)  
043 SUBROUTINE TO SMOOTH A BLOCK OF DATA IN MEMORY  
044 SUBROUTINE TO REDISTRIBUTE A BLOCK OF DATA  
045 PACK A CHARACTER IN A BUFFER IN OS8 FORMAT  
046 UNPACK A CHARACTER FROM A BUFFER IN OS8 FORMAT  
049 SEARCH A LIST FOR A MATCH  
050 LIST SEARCH, CROSS-FIELD CALLABLE  
053 UNPACK CHAR-BY-CHAR FOR OS8 HANDLERS  
054 UNPACK CHAR-BY-CHAR FOR OS8 HANDLERS  
055 UNPACK AND PRINT OS8 BUFFER (DEVICE HANDLER)  
056 PUSH AND POP OPERATORS FOR DIFFERENT STACKS  
057 FILL A ROTATING BUFFER QUEUE (FIRST IN FIRST OUT)  
058 RESET (CLEAR) A ROTATING BUFFER QUEUE  
059 FETCH THE NEXT ITEM FROM THE HEAD OF THE QUEUE  
060 COMBINED ROTATING BUFFER OPERATORS, CROSS-FIELD CALLABLE  
063 FIND THE SMALLEST HOLE IN A LIST, JUST BIG ENOUGH  
065 INITIALIZE THE FREECORE AREA  
066 REQUEST A FREE BLOCK  
067 RELEASE A BLOCK TO FREECORE  
068 RELEASE A QUEUE OF FORWARD LINKED BLOCKLETS TO FREECORE  
069 MAKE A BUFFER OR 'QUEUE'  
070 READ NEXT ELEMENT FROM THE TAIL OF A ROTATING BUFFER (QUEUE)  
071 WRITE AN ELEMENT ONTO THE TOP OF A BUFFERQUEUE  
072 KILL THE BUFFER QUEUE  
082 ASCII STRING GENERATOR

REVISIONS TO THE PDP8 COOKBOOK VOLUME 1

\*\*\*\*\*

O10 CAN BE IMPROVED BY CHANGING THE FIRST INSTRUCTION  
'CMA' INTO 'CLA CMA'.  
THIS ROUTINE IS ,HOWEVER, SUPERCEDED BY O10A.

\*\*\*\*\*

O13 EXCLUSIVE OR ROUTINE CAN BE IMPROVED:

```
TAD A
AND B
CMA IAC
CLL RAL
TAD A
TAD B
```

OR AS FOLLOWS:

```
TAD A
AND B
CLL RAL
CIA
TAD A
TAD B
```

THE NOR ROUTINE CAN BE IMPROVED:

```
TAD A
CMA
AND B
TAD A
CMA
```

```

/O10A PAL MESSAGE PRINTER (REPLACES # 010)
/PRINTS A MESSAGE CODED WITH THE
/PALD OR PAL8 PSEUDO-OF "TEXT"
/
/PALD AND PAL8 COMPATIBLE EXCEPT CAR RET & LINEFEED.
/
/CALL: JMS PRMSG
/      MSG
/      RETURN (AC=0)
/
/MSG.  TEXT 'ABC8Z' /CODED AS 010Z;0370;6200
/
PRMSG, 0
  CLA CMA
  TAD I PRMSG          /SAVE POINTER
  DCA PRMSG3
  ISZ PRMSG           /FOR RETURN
PRMSG1, CLA CMA
  DCA PRMSG4          /UNPACKSWITCH
  ISZ PRMSG3         /NEXT WORD
  TAD I PRMSG3       /FETCH WORD
  RTR                /*
  RTR                /MAY BE CODED 'BSW' FOR 8E
  RTR                /*
PRMSG2, AND C77      /MASK 6 BITS
  SNA                /END OF LIST?
  JMP I PRMSG        /YES
  TAD C240           /RECODE
  AND C77           /CHARACTER TO
  TAD C240           /BE PRINTED
  JMS PRINT         /AND PRINT
  ISZ PRMSG4        /TEST L-R SWITCH
  JMP PRMSG1        /LEFT
  TAD I PRMSG3      /RIGHT
  JMP PRMSG2
/
PRMSG3, 0           /POINTER
PRMSG4, 0           /UNPACKSWITCH 0=R; 1=L
/
/GENERAL CONSTANTS
C77, 77
C240, 240

```

```

/O12A CHECK IF OCTAL DIGIT (REPLACES # 012)
/ROUTINE CHECKS WHETHER THE AC IS AN OCTAL DIGIT
/
/TAD CHARACTER
/JMS OCTCHK
/NOT OCTAL RETURN
/OCTAL RETURN
/
OCTCHK, 0
    TAD M260
    AND C7770           /OR "AND M10"
    SNA CLA
    ISZ OCTCHK         /RETURN FOR OCTAL DIGIT
    JMP I OCTCHK
/
/GENERAL CONSTANTS
M260, -260
C7770, 7770

```

```

/O12B CHECK WHETHER OCTAL OR NOT
/ROUTINE CAN BE MORE PRACTICAL IF 'SZL CLA' BECOMES
/'SZL' OR 'SNL' IN WHICH CASE THE 'OCTALRETURN'
/IS WITH THAT DIGIT IN THE AC. THE OTHER RETURN IS
/WITH AC=-260

```

```

    10
    -270
OCTCHK, 0
    TAD OCTCHK-1
    CLL
    TAD OCTCHK-2
    SZL CLA
    ISZ OCTCHK
    JMP I OCTCHK

```



```

/O19A REV. 9 FEB 1973
/ SUBROUTINE READS A DECIMAL NUMBER FROM KEYBD
/RUBOUT REMOVES NUMBER COMPLETELY
/
/
/CALL :JMS DECINF
/ RETURN WITH NUMBER BINARY IN AC
/
/

```

```

DECINF, 0
  CLA
  DCA DECNUM /CLEAR REGISTER
  JMS READ /READ CHAR FROM KEYBOARD
  TAD CHAR
  JMS PRINT /PRINT THAT CHAR
  TAD CHAR /GET CHARACTER
  TAD M377 /IS IT RUBOUT?
  SNA CLA
  JMP DECINF+1 /YES READ ALL OVER AGAIN
  TAD CHAR /NO
  TAD M260
  SFA /CHAR>=260?
  JMP DECOUT /NO, CHARACTER IS DELIMETER
  TAD M12 /YES
  SMA CLA /CHAR<272?
  JMP DECOUT /NO, CHAR IS DELIMETER
  TAD DECNUM /YES, CHAR IS FIGURE
  CLL RTL /NUMB*4
  TAD DECNUM /NUMB*4+1=NUMB*5
  CLL RAL /NUMB*5*2=NUMB*10
  TAD CHAR /ADD LAST FIGURE
  TAD M260
  DCA DECNUM /DECIMAL NUMBER
  JMP DECINF+3

```

```

/
DECOUT, CLA
  TAD DECNUM
  JMP I DECINF /EXIT
/

```

```

/VARIABLES
/

```

```

DECNUM, 0
/

```

```

/GENERAL CONSTANTS

```

```

M12, -12
M260, -260
M377, -377

```

040

```
/SUBROUTINE TO DISPLAY A BLOCK OF DATA
/DISPLAY CONTROL: VC8-E
/CALLING SEQUENCE:
/      JMS DISPLA
/      START ADDRESS OF MEMORY BLOCK MINUS 1
/      MINUS NO OF WORDS (MAX -255)
/      RETURN      /AC=0
```

IR1=10

```
      0
      7000
      0
DISPLA, 0
      TAD I DISPLA      /GET START ADDRESS
      DCA IR1
      ISZ DISPLA
      TAD I DISPLA      /GET NO. OF WORDS
      DCA DISPLA-1
      TAD DISPLA-2      /GET LEFT POINT ON DISPLAY
      DCA DISPLA-3
DISNEX, TAD DISPLA-3      /GET X-POINT
      DILX
      CLA
      TAD I IR1          /GET DATA
      DILY
      CLA
      DISD              /WAIT FOR SETTLING
      JMP .-1
      DIXY
      ISZ DISPLA-3      /INCREMENT X-POINT
      NOP
      ISZ DISPLA-1      /INCREMENT COUNT
      JMP DISNEX
      ISZ DISPLA        /SET RETURN ADDRESS
      JMP I DISPLA      /RETURN
```

```

/SUBROUTINE TO DISPLAY INPUT FROM AN ANALOG CHANNEL
/INPUT: AD8-E +AM8-E, DISPLAY CONTROL: VC8E
/CALLING SEQUENCE:
/      JMS MULDIS
/      MULTIPLEXER CHANNEL
/      RETURN      /AC=0

```

```

0
0
-1777
7000
MULDIS, 0
TAD I MULDIS      /GET CHANNEL
ADLM
TAD MULDIS-1     /GET LEFT POINT ON DISPLAY
DCA MULDIS-4
TAD MULDIS-2     /GET MINUS NO. OF POINTS
DCA MULDIS-3
MULNEX, TAD MULDIS-4 /GET X-POINT
DILX
CLA
JMS MULSAM      /GET SAMPLE
DILY
CLA
DISD           /WAIT FOR SETTLING
JMP .-1
DIXY
ISZ MULDIS-4   /INCREMENT X-POINT
NOP
ISZ MULDIS-3   /INCREMENT COUNT
JMP MULNEX     /GO TO NEXT POINT
ISZ MULDIS     /SET RETURN ADDRESS
JMP I MULDIS   /RETURN

MULSAM, 0
ADST           /START CONVERSION
ADSK
JMP .-1       /WAIT FOR CONVERSION DONE
ADRB          /READ AD BUFFER
JMP I MULSAM

```

```

/SUBROUTINE TO INPUT A BLOCK OF DIGITAL DATA
/INPUT VIA THE DIGITAL I/O DR8-E
/CALLING SEQUENCE:
/      JMS DIGIN
/      START ADDRESS OF MEMORY BLOCK MINUS 1
/      MINUS NO OF WORDS
/      RETURN      /AC=0
/START DATA BLOCK:      BIT 10
/WORD COMMAND:          BIT 11
/END DATA BLOCK:      BIT 9

```

IR1=10

```

DIGIN, 0
      0
      TAD I DIGIN      /GET START ADDRESS
      DCA IR1
      ISZ DIGIN
      TAD I DIGIN      /GET NO. OF WORDS
      DCA DIGIN-1
      DBCO              /CLEAR OUTPUT REGISTER
      DBCI              /CLEAR INPUT REGISTER
      CLA CLL IAC RAL  /START DATA BLOCK
      DBSO              /SET OUTPUT REGISTER
      DBCO              /CLEAR OUTPUT REGISTER
      CLA CLL IAC      /WORD COMMAND PULSE
      DBSO
      DBCO
      CLA CLL
      DBSK              /WAIT FOR FLAG
      JMP .-1
      DBRI              /READ INPUT REGISTER
      DBCI              /CLEAR INPUT REGISTER
      DCA I IR1
      ISZ DIGIN-1      /INCREMENT COUNTER
      JMP .-12         /GO TO NEXT WORD
      CLA CLL IAC RTL  /END DATA BLOCK
      DBSO
      DBCO
      CLA CLL
      ISZ DIGIN        /SET RETURN ADDRESS
      JMP I DIGIN      /RETURN

```

```

/SUBROUTINE TO SMOOTH A BLOCK OF DATA IN MEMORY
/DATA WILL BE SMOOTHED WITH THE FILTER:
/A(I)= 1/4.A(I-1) +1/2.A(I) +1/4.A(I+1)
/CALLING SEQUENCE:
/      JMS FILTER
/      START ADDRESS OF MEMORY BLOCK
/      MINUS NO OF POINTS
/      RETURN      /AC=0
0
0
0
0
0
0
FILTER, 0
TAD I FILTER      /GET START ADDRESS
DCA FILTER-1      /INPUT POINTER
ISZ FILTER
TAD I FILTER      /GET MINUS NO. OF POINTS
DCA FILTER-2      /POINT COUNT
TAD FILTER-1
DCA FILTER-3      /OUTPUT POINTER
TAD I FILTER-1    /GET FIRST POINT
DCA FILTER-5      /SAVE IT IN OUT-STORE
FILNEX, TAD I FILTER-1 /GET FIRST POINT
JMS FILHAL
JMS FILHAL        /DIVIDE BY 4
DCA FILTER-4      /SAVE IT IN IN-STORE
ISZ FILTER-1      /INCREMENT INPUT POINTER
TAD I FILTER-1    /GET SECOND POINT
JMS FILHAL        /DIVIDE BY 2
TAD FILTER-4      /ADD AND
DCA FILTER-4      /SAVE IT IN IN-STORE
ISZ FILTER-1      /INCREMENT INPUT POINTER
TAD I FILTER-1    /GET THIRD POINT
JMS FILHAL
JMS FILHAL        /DIVIDE BY 4
TAD FILTER-4      /ADD AND
DCA FILTER-4      /SAVE IT IN IN-STORE
TAD FILTER-5      /GET PREVIOUS RESULT
DCA I FILTER-3    /PUT IT BACK IN MEMORY
TAD FILTER-4      /GET CURRENT RESULT
DCA FILTER-5      /SAVE IT FOR NEXT OUTPUT
ISZ FILTER-3      /INCREMENT OUTPUT POINTER
TAD FILTER-1      /GET INPUT POINTER
CIA
CMA
CMA
DCA FILTER-1
ISZ FILTER-2      /INCREMENT POINT COUNT
JMP FILNEX        /GO TO NEXT POINT
ISZ FILTER        /SET RETURN ADDRESS
JMP I FILTER      /RETURN

```

```
FILHAL, 0
SPA                               /IS IT POSITIVE?
JMP .+4
CLL RAR                           /YES, DIVIDE POS.
CLL                               /NUMBER BY TWO
JMP I FILHAL                       /AND JMP BACK
STL                               /NO, DIVIDE NEG.
RAR                               /NUMBER BY TWO
CLL
JMP I FILHAL                       /AND JMP BACK
```

/SUBROUTINE TO REDISTRIBUTE A BLOCK OF DATA.  
 /A SIGNAL, CONSISTING OF X SAMPLES IS REDISTRIBUTED  
 /INTO A SIGNAL CONSISTING OF THE NEAREST LOWER  
 /2\*N SAMPLES. (MAX 2048)  
 /END OF SIGNAL CONDITION: 10 SUCCEEDING ZERO'S.

/GENERAL: X POINTS BECOME Y=2\*N POINTS  
 / (X-1) (X-1)  
 /Y(I)=(1-REST OF I.-----).CONTENTS OF I. ----- +  
 / (Y-1) (Y-1)  
 / (X-1) (X-1)  
 / (1-(1-REST OF I.-----)).CONTENTS OF (I.-----+1)  
 / (Y-1) (Y-1)  
 /THIS OPERATION IS NECESSARY PRIOR TO APPLYING  
 /A FAST FOURIER TRANSFORM TO A PERIODIC SIGNAL,  
 /NOT CONSISTING OF 2\*N SAMPLES.

/NECESSARY HARDWARE: KES-E EXTENDED ARITHMETIC EL.  
 /CALLING SEQUENCE:

/ JMS REDIST  
 / START ADDRESS OF MEMORY BLOCK MINUS 1  
 / MINUS NO. OF POINTS OF SIGNAL BUFFER  
 / RETURN /AC=0

IR1=10  
 REDSTA, 0  
 REDPOI, 0  
 RED0, 0  
 REDM11, -11  
 REDCNT, 0  
 REDNO, 0  
 REDCMP, 0  
 REDNEW, 0  
 REDMIN, -1  
 REDRES, 0  
 REDLOC, 0  
 REDPOS, 4000  
 REDFAC, 0  
 REDIST, 0

TAD I REDIST /GET START ADDRESS  
 DCA IR1  
 TAD I REDIST  
 IAC  
 DCA REDSTA  
 ISZ REDIST  
 TAD I REDIST /GET - NO. OF POINTS  
 DCA REDPOI  
 TAD I REDIST  
 DCA REDTLR  
 ISZ REDIST /SET RETURN ADDRESS

REDNUL	TAD I IRI	/GET WORD
	ISZ REDTLR	/INCREMENT WORD COUNT
	SKP	
	JMP I REDIST	/RETURN, NO END OF SIGNAL
	SNA	/TEST FOR AC=0
	JMP .+3	
	CLA CLL	
	JMP .-7	/NO, TAKE NEXT WORD
	TAD IRI	/YES, STORE LOCATION
	DCA RED0	/OF FIRST ZERO
	TAD REDM11	
	DCA REDCNT	
	TAD I IRI	/ADD NEXT 9 WORDS
	ISZ REDCNT	
	JMP .-2	
	SZA CLA	/TEST FOR SUM =0
	JMP REDNUL	/NO, GO ON
	TAD REDSTA	/YES AND
	CIA	/CALCULATE
	TAD RED0	/NO. OF POINTS
	DCA REDNO	
	CLA CLL CML RAR	/MAKE 4000
	DCA REDCMP	
	TAD REDNO	
	AND REDCMP	/AND WITH 2*N
	SNA CLA	/TEST FOR NON ZERO
	JMP .+4	
	TAD REDCMP	/YES, THIS IS THE
	DCA REDNEW	/NEW NO. OF POINTS
	JMP .+5	
	TAD REDCMP	/NO, DIVIDE
	CLL RAR	/BY TWO
	DCA REDCMP	
	JMP .-12	/AND GO AGAIN
	CAM	
	SWAB	
	TAD REDNEW	/GET 2*N POINTS
	CIA	
	DCA REDTLR	/PUT IN COUNTER
	DCA RED0	/CLEAR I
	TAD REDSTA	/GET START ADDRESS
	TAD REDMIN	/SUBTRACT ONE
	DCA IRI	
	TAD REDNO	/GET ORIGINAL NO. OF POINTS
	TAD REDMIN	/SUBTRACT ONE
	DCA REDNO	/THIS IS: (X-1)
	TAD REDNEW	/GET NEW NO. OF POINTS
	TAD REDMIN	/SUBTRACT ONE
	DCA REDNEW	/THIS IS: (Y-1)



REDNEX, TAD REDNO	/GET (X-1)
MQL	
MUY	
REDØ	/MULTIPLY WITH I
DVI	
REDNEW	/DIVIDE BY (Y-1)
DCA REDRES	/SAVE REST
SWP	/QUOTIENT TO AC
TAD REDSTA	/GET START ADDRESS
DCA REDLOC	/SUM IS: LOCATION
TAD REDNEW	/GET (Y-1)
MQL	
TAD REDRES	/GET REST
SAM	/RESULT: (Y-1)-REST
MQL	/PUT IN MQ
TAD I REDLOC	/GET CONTENTS OF LOC.
TAD REDPOS	/MAKE POS.
DCA REDCMP	
MUY	/MULT. (Y-1)-REST
REDCMP	/WITH POS. CONTENTS OF LOC.
DVI	/DIVIDE RESULT
REDNEW	/BY (Y-1)
SWP	
DCA REDFAC	/SAVE FIRST FACTOR
CAM	
ISZ REDLOC	/INCREMENT LOCATION
TAD REDRES	/GET REST
MQL	
TAD I REDLOC	/GET CONTENTS OF LOC. +1
TAD REDPOS	/MAKE POS.
DCA REDCMP	
MUY	/MULTIPLY REST WITH
REDCMP	/POS. CONTENTS OF LOC. +1
DVI	/DIVIDE BY
REDNEW	/(Y-1)
SWP	
TAD REDFAC	/ADD FIRST FACTOR
TAD REDPOS	/GET RIGHT SIGN
DCA I IRI	/AND STORE IN MEMORY
ISZ REDØ	/INCREMENT I
ISZ REDTLR	/INCREMENT COUNTER
JMP REDNEX	/NEXT POINT
TAD REDNEW	/CALCULATE END ADDRESS
TAD REDSTA	/OF SIGNAL
DCA IRI	
TAD REDPOI	/GET -NUMBER OF POINTS
TAD REDNEW	/IN SIGNAL BUFFER
IAC	/COMPUTE REST NO. OF POINTS
DCA REDTLR	
DCA I IRI	/CLEAR REST OF BUFFER
ISZ REDTLR	
JMP .-2	
JMP I REDIST	/RETURN

```

/      PACK A CHARACTER IN A BUFFER IN OS/8 FORMAT
/      CAN BE USED FOR BUFFERS UP TO 31 PAGES
/      (NOT USING LAST PAGE OF FIELD)
/      PARAMETERS ARE:
/          CURFLD: FIELD OF SUBROUTINE
/          BUFLD:  FIELD OF BUFFER
/          BUFBE, BUFEND: DEFINE SIZE OF BUFFER
/      CALL:   TAD   CHAF
/             JMS   PACKB
/             BUFFER FULL RETURN(AC=0)
/             NORMAL RETURN (AC=0)

```

```

0          /TEMPORARY STORAGE
PACKB,    ---
DCA       PACKB-1 /SAVE CHARACTER
TAD       PACKSW  /TEST PACKSWITCH
CDF       BUFLD
SZA
JMP       PACKB1  /IF -2
TAD       PACKB-1 /GET CHARACTER
DCA I     PACPTR  /INSERT IN BUFFER
TAD       PACPTR
CLL RAR   /IS POINTER ODD ?
SNL CLA   /SKIP IF YES
JMP       .+4
CLA CLL  CMA RAL /SET PACKSWITCH TO -2
DCA       PACKSW
SKP
ISZ       PACPTR  /INCREMENT POINTER IF EVEN
JMP       PACKB2  /GO TO EXIT
PACKB1,  CLA CLL  CMA
TAD       PACPTR  /DECREMENT POINTER
DCA       PACPTR
TAD       PACKB-1 /GET CHARACTER
RTL
RTL       /SHIFT 4 POSITIONS TO LEFT
DCA       PACKB-1 /SAVE TEMPORARY
TAD       PACKB-1
AND       C7400   /KILL BITS 4-11
TAD I     PACPTR
DCA I     PACPTR  /INSERT IN BUFFER
ISZ       PACPTR  /INCREMENT ADDRESSPOINTER
ISZ       PACKSW  /INCREMENT PACKSWITCH
JMP       PACKB1+3 /AGAIN IF PACKSWITCH NONZERO
TAD       PACEND
CMA CLL   /TEST FOR BUFFER END
TAD       PACPTR
SNL CLA   /SKIP IF FULL
JMP       PACKB2
TAD       PACBEG  /INITIALIZE POINTER
DCA       PACPTR
SKP
PACKB2,  ISZ       PACKB  /NORMAL RETURN
CDF       CURFLD
JMP I     PACKB

```

```

PACPTR,  BUFBE
PACKSW,  0
PACBEG,  BUFBE
PACEND,  BUFE
C7400,   7400

```

Ø46

```

/   UNPACK A CHARACTER FROM A BUFFER IN OS/8 FORMAT
/
/   CAN BE USED FOR BUFFERS UP TO 31 PAGES
/       (NOT USING LAST PAGE OF FIELD)
/
/   PARAMETERS ARE:
/       CURFLD: FIELD OF SUBROUTINE
/       BUFLD:  FIELD OF BUFFER
/       BUFBEG, BUFEND: DEFINE SIZE OF BUFFER
/
/   CALL:  CLA
/          JMS      UNPACK
/              RETURN; IF LINK=1: BUFFER EMPTY
/                  IF LINK=0: NORMAL RETURN
/
/   RETURNS WITH CHARACTER IN AC

```

```

Ø           /TEMPORARY STORAGE
UNPACK, .-.
TAD        UNPSW  /TEST PACKSWITCH
CDF        BUFLD
SZA CLA
JMP        UNPAC1 /IF -2
TAD I     UNPPTR  /GET FROM BUFFER
AND        C377  /KILL BITS 0-3
DCA        UNPACK-1 /SAVE TEMPORARY
TAD        UNPPTR /IS POINTER EVEN ?
CLL RAR
SNL CLA    /SKIP IF NO
JMP        .+4
CLA CLL   CMA RAL /SET PACKSWITCH TO -2
DCA        UNPSW
SKP        /NO INCREMENT
ISZ        UNPPTR
JMP        UNPAC2 /GO TO EXIT
UNPAC1, DCA    UNPACK-1 /MAKE TEMP. LOCATION ZERO
TAD I     UNPPTR  /GET WORD
AND        C7400 /KILL BITS 4-11
TAD        UNPACK-1
CLL RTR
RTR
DCA        UNPACK-1 /SAVE TEMPORARY
CLA CMA
TAD        UNPPTR  /DECREMENT POINTER
DCA        UNPPTR
ISZ        UNPSW  /INCREMENT PACKSWITCH
JMP        UNPAC1+1 /AGAIN IF NONZERO
CLA CLL   CML IAC RAL
TAD        UNPPTR
DCA        UNPPTR  /POINTER +3
TAD        UNPEND  /TEST FOR BUFFER END
CMA CLL
TAD        UNPPTR
SNL CLA    /SKIP IF EMPTY
JMP        UNPAC2

```

```
      TAD      UNPBEG  /INITIALIZE POINTER
      DCA      UNPPTR
      SKP      /LINK=1
UNPAC2, CLL    /NORMAL RETURN
      TAD      UNPACK-1 /GET CHARACTER
      CDF      CURFLD
      JMP I    UNPACK
```

```
UNPPTR, BUFBEQ
UNPSW,  0
UNPBEG, BUFBEQ
UNPEND, BUFEQD
```

```
C377,   377
C7400,  7400
```

/ PARITY GENERATOR  
/  
/ GENERATES ODD OR EVEN PARITY BIT (8TH BIT)  
/  
/ CALL: TAD CHAR  
/ JMS PARITY  
/ RETURN (WITH CHARACTER IN AC)

0 /CHARACTER TEMPORARY  
0 /PARITY SUM  
PARITY, .-.  
AND C177 /KILL 8TH BIT  
DCA PARITY-2  
DCA PARITY-1  
TAD PARITY-2/GET CHARACTER  
PARIT1, CLL RAR  
SZL /TEST BIT  
ISZ PARITY-1  
SZA /NEXT BIT ?  
JMP PARIT1 /YES  
TAD PARITY-1/GET PARITY SUM  
RAR  
SZL CLA /FOR EVEN PARITY;  
/ IF ODD PARITY: SNL CLA  
TAD C200 /SET PARITY BIT  
TAD PARITY-2/GET CHARACTER AND  
JMP I PARITY / RETURN

C177, 177  
C200, 200

```

/      SKIP ON FLAG WITH TIMED OUT RETURN
/
/      CALL:   CLA
/              JMS      SKPOUT
/              TIME OUT (IN MILLISECONDS)
/              SKIP INSTRUCTION
/              TIMED OUT RETURN
/              NORMAL RETURN

```

```

Ø      /TIMER 1
Ø      /TIMER 2
-14Ø   /PRESET TIMER 2 (ADJUST FOR 1 MILLISECOND)
SKPOUT, .-.
TAD I  SKPOUT /GET PRESET TIMER 1
CIA
DCA    SKPOUT-3
ISZ   SKPOUT
TAD I  SKPOUT /GET SKIP INSTRUCTION
DCA    SKPOU2
ISZ   SKPOUT
SKPOU1, TAD   SKPOUT-1
DCA    SKPOUT-2/SET TIMER 2
SKPOU2, Ø      /OVERLAID BY SKIP INSTRUCTION
JMP    .+3
ISZ   SKPOUT /SKIPPED !
JMP I  SKPOUT
ISZ   SKPOUT-2/OVERFLOW TIMER 2 ?
JMP    SKPOU2 /NO
ISZ   SKPOUT-3
JMP    SKPOU1
JMP I  SKPOUT /TIMED OUT

```

/SEARCH A LIST FOR A MATCH  
 /THE ROUTINE SEARCHES IN A LIST FOR A MATCH WITH AC.  
 /IT HAS TWO RETURNS : FOUND AND NOT FOUND;  
 /BOTH WITH AC=0. THE LIST TERMINATOR IS ALSO 0.  
 /THE FIRST ELEMENT HAS ELEMENTNUMBER 0

/ TAD (ELEMENT  
 / JMS SORTC  
 / LIST-1  
 / NOT IN LIST RETURN /AC=0  
 / NORMAL RETURN /AC=0

/LIST, 301,302,303,304,.....,0/ZERO IS TERMINATOR

SORTCN, 0 /COUNTER CAN BE ON PAGE 0  
 0 /POINTER  
 0 /- AC  
 SORTC, -- /TEST FOR CHAR. IN LIST  
 CIA  
 DCA SORTC-1 /SAVE -AC  
 DCA SORTCN /CLEAR COUNTER  
 TAD I SORTC /GET ARG1  
 ISZ SORTC /FOR CORRECT RETURN  
 DCA SORTC-2 /SAVE POINTER  
 ISZ SORTC-2 /POINTER+1  
 TAD I SORTC-2 /GET LIST ELEMENT  
 ISZ SORTCN  
 SNA /ZERO?  
 JMP I SORTC /YES, ELEMENT NOT FOUND  
 TAD SORTC-1 /COMPARE  
 SZA CLA /EQUAL?  
 JMP --7 /NO, TRY NEXT ELEMENT  
 ISZ SORTC /YES, SET UP RETURN  
 JMP I SORTC /AC=0

/LIST SEARCH,CROSS FIELD CALLABLE  
 /THE ROUTINE MATCHES THE AC AGAINST ALL ELEMENTS  
 /OF A LIST.IN CASE OF A MATCH IT TAKES THE NORMAL  
 /RETURN WITH THE OFFSET IN THE LIST IN THE AC.  
 /IN CASE IT ENCOUNTERS A 0000 IN THE LIST, IT  
 /TAKES THE ERROR RETURN,ALSO WITH OFFSET IN AC.  
 /THE LIST IS ASSUMED TO BE IN FIELD OF CALL.  
 /IN THE EXAMPLE: ELEMENT 301 HAS OFFSET 0

/ TAD (AC  
 / CIF 0  
 / JMS LIST  
 / LST- . /MARK THIS CONSTRUCTION!!!  
 / NOT IN LIST RETURN /AC=OFFSET IN LIST  
 / NORMAL RETURN(FOUND) /AC=OFFSET IN LIST  
 /LST, 301;302;303;304;0 /ZERO IS TERMINATOR!!!

0 /OFFSET COUNTER  
 0 /POINTER  
 0 /-AC

LIST, 0  
 CIA  
 DCA LIST-1  
 CMA /NOTE!COUNTER OVERFLOWS INSTANTLY  
 DCA LIST-3 /CLEAR OFFSET COUNTER  
 TAD I LIST /MAKE ARG ABSOLUTE  
 TAD LIST  
 DCA LIST-2  
 ISZ LIST /FOR RETURN  
 LIST1, ISZ LIST-3  
 ISZ LIST-2  
 TAD I LIST-2  
 SNA /ZERO?  
 JMP LISTR  
 TAD LIST-1  
 SZA CLA /MATCH FOUND?  
 JMP LIST1 /N  
 ISZ LIST  
 LISTR, RDF  
 TAD C6203  
 DCA .+2  
 TAD LIST-3  
 0  
 JMP I LIST



/RELATIVE BRANCHER; CROSS FIELD CALLABLE  
 /THIS BRANCH ROUTINE CAN BE CALLED FROM ANY FIELD.  
 /IT ASSUMES THE LIST IN THE FIELD OF CALL, AND THE  
 /DESTINATION ADDRESSES TOO. IT WORKS WITH RELATIVE  
 /DISTANCES AND IS THEREFORE USEFUL FOR RUNTIME RELO-  
 /CATABLE PROGRAMS.

```

/      TAD (AC
/      CIF 0          /IF BRANCH RESIDES IN FIELD 0
/CALL, JMS I (BRANCH
/      LIST--1      /RELATIVE DISTANCE TO LIST
/      NOT IN LIST RETURN      /AC=0

/LIST, 215;CR-.
/      212;LF-.
/      377;RUB-.
/      0              /ZERO IS TERMINATOR !!!!

      0              /TEMP AC;NEGATIVE
      0              /POINTER
BRANCH, --.         /ENTER WITH AC=ELEMENT
      CIA
      DCA BRANCH-2
      TAD I BRANCH
      TAD BRANCH      /MAKE POINTER ABSOLUTE
      DCA BRANCH-1
      ISZ BRANCH      /FOR RETURN
BRAN1, ISZ BRANCH-1
      TAD I BRANCH-1 /FETCH ELEMENT
      SNA              /IS IT 0?(END OF LIST)
      JMP BRANR       /Y
      TAD BRANCH-2
      ISZ BRANCH-1
      SZA CLA         /MATCH?
      JMP BRAN1       /N,LOOP
      TAD I BRANCH-1 /PICK DISTANCE TO DESTINATION
      TAD BRANCH-1   /MAKE ABSOLUTE
      DCA BRANCH
BRANR, RDF          /FIX FIELD AGAIN, AND JUMP
      TAD C6203
      DCA .+1
      0
      JMP I BRANCH
C6203, 6203
  
```

```

/GENERAL SETUP FOR OS8 HANDLERS
/ENTER WITH LINK=1 FOR READ ONLY DEVICE
/LINK =Ø FOR WRITE ONLY DEVICE
/ONLY APPLIES TO NON-BLOCK-ORIENTED DEVICES.
/IT CREATES A WORDCOUNT(WC) SET TO -WORDCOUNT-1
/AND A START ADDRESS OF BUFFER (CA),
/AND A CDF TO THE BUFFER FIELD IN 'SETCDF'.
/'ENTRY' IS THE ENTRYPPOINT OF THE HANDLER.
/IT LEAVES THE SUBROUTINE WITH 'ENTRY' POINTING
/TO 'STARTING BLK #' FOR BLOCK ORIENTED DEVICES.
/AND DATAFIELD STILL SET TO FIELD OF CALL.

```

```

77ØØ
7Ø

```

```

TEM=.
SETUP, Ø
RDF /SET UP RETURN
TAD C62Ø3
DCA XIT+2
TAD I ENTRY
AND SETUP-1 /7Ø
TAD SETCD /MAKE CDF
DCA SETCDF /FIELD OF BUFFER
RAR /GET LINK
TAD I ENTRY /GET FUNCTION WORD
ISZ ENTRY
SPA /CHECK READ/WRITE
JMP ERR /UNRECOVERABLE ERROR
AND SETUP-2 /77ØØ
CLL CML CMA RAL /MAKE -WORDCOUNT-1
DCA WC
TAD I ENTRY
ISZ ENTRY
DCA CA /CURRENT ADDRESS
JMP I SETUP

ERR, CLA CLL CML RAR /SIGNAL "PERMANENT IO ERROR"
XIT, ISZ ENTRY
ISZ ENTRY
Ø /CDF CIF
JMP I ENTRY

SETCD, CDF Ø /SOMEWHERE IN HANDLER
C62Ø3, CDF CIF Ø
CA, Ø
WC, Ø

```

/UNPACK CHAR BY CHAR ROUTINE FOR OS8 HANDLERS.  
 /NEEDS A WORDCOUNT SET TO -WORDCOUNT-1, AND A POINTER  
 /SET TO CURRENT ADDRESS (BEGIN OF BUFFER).  
 /AT THE VERY FIRST ENTRY: PACKSWITCH SHOULD BE 0.  
 /THE WORDCOUNT IS INCREMENTED EVERY 3 CHARACTERS.  
 /IF THE BUFFER IS EXHAUSTED, THE ROUTINE JUMPS TO XIT.  
 /IT EXITS WITH THE DATAFIELD STILL SET TO THE  
 /FIELD OF BUFFER

PACKSW, 0                    /PAKSWITCH.POS. MEANS L.S. 8 BITS  
                               /NEG. MEANS MOST SIGN 4 AND 4 BITS.  
                               7400  
                               377

UNPACK, .-.                 /ENTER WITH AC=0  
 SETCDF, 0                   /SET TO CDF X BY SETUP ROUTINE

TAD PACKSW  
 SPA  
 JMP UNP1  
 SZA  
 CLA CLL CMA RTL /AC=-3  
 DCA PACKSW  
 ISZ PACKSW                 /PAKSW IS -2 OR +1  
 TAD I CA                   /FETCH LS 8 BITS  
 AND UNPACK-1  
 ISZ CA                     /FOR NEXT  
 ISZ WC  
 JMP I UNPACK               /EXIT WITH NEXT CHAR IN AC

C7600, 7600                 /CLA  
                               DCA PACKSW                 /RESET PAKSWITCH FOR NEXT ENTRY  
                               JMP XIT

UNP1, TAD CA                 /SET POINTER BACK  
       DCA CA  
       CLL  
       DCA TEM  
       TAD I CA  
       AND UNPACK-2  
       TAD TEM  
       RTL  
       RTL  
       ISZ CA  
       ISZ PACKSW            /LOOP 2 TIMES; ALSO SETS PAKSW=0  
       JMP UNP1+3  
       RAL  
       JMP I UNPACK

CA, 0  
 WC, 0  
 TEM, 0                     /TEMP. LOCATION, SOMEWHERE IN HANDLER

/UNPACK CHAR BY CHAR FOR OS8 HANDLERS.  
 /ROUTINE UNPACKS AN OS8 FORMAT ASCII BUFFER CHARACTER  
 /BY CHARACTER. IT NEEDS A POINTER (CA) SET TO THE  
 /BEGINNING OF THE BUFFER, AND A WORDCOUNT (WC) SET  
 /TO - THE NUMBER OF WORDS IN THE BUFFER -1.  
 /THE LOCATION 'SETCDF' NEEDS TO BE SET TO THE FIELD  
 /WHERE THE BUFFER RESIDES.  
 /THE PACKSWITCH HAS 3 VALUES:0 FOR THE FIRST OF 3 CHARS.  
 /1 FOR THE SECOND, AND 2 FOR THE 3RD.  
 /THE PACKSWITCH SHOULD BE 0 WHEN ENTERED FOR THE FIRST  
 /TIME. THE ROUTINE LEAVES THE DATAFIELD TO THE FIELD  
 /OF BUFFER UPON EXIT. IF BUF EMPTY THEN JUMP TO 'XIT'.

```

PACKSW, 0          /0, 1, OR 2
          7400
          377

UNPACK, ---      /ENTER WITH AC=0
SETCDF,  CDF     /OVERLAID
          TAD PACKSW
          RAR
          SZL          /1?
          JMP UNP2     /Y
          SZA CLA
          JMP UNP3     /2
UNP1,   TAD I CA
          AND UNPACK-2
          CLL RTR
          DCA TEM     /BYTE 3 ALREADY PARTLY PREPARED
          TAD I CA
          AND UNPACK-1
          ISZ CA
          ISZ PACKSW
          ISZ WC      /INCR. TWICE, EVERY 3 BYTES
          JMP I UNPACK
C7600,  7600     /CLA
          JMP XIT

UNP2,   TAD I CA
          AND UNPACK-2 /PREPARE 3RD BYTE
          CLL RTR
          RTR
          RTR
          TAD TEM
          JMP UNP1+2

UNP3,   DCA PACKSW /PREPARE FOR NEXT ENTRY
          TAD TEM
          JMP I UNPACK

TEM,    0
CA,     0
WC,     0
          /SOMEWHERE IN THE HANDLER
  
```

/UNPACK AND PRINT OS8 BUFFER; IN HANDLER  
 /THIS PROGRAM PART IS USEFUL FOR HANDLERS THAT HAVE  
 /AN OUTPUT ROUTINE THAT LEAVES BITS 0-3 AS THEY  
 /ARE. THE WORDCOUNT (WC) SHOULD BE SET TO -WORDCOUNT/2  
 /AS IT INCREMENTS EVERY 2 LOCATIONS (3 BYTES).  
 /THE ROUTINE IS ENTERED AND EXITED WITH THE DATAFIELD  
 /SET TO THE FIELD OF BUFFER.

```

UNP,      TAD I CA          /FIRST BYTE
          ISZ CA
          JMS OUTPUT
          AND C7400
          DCA TEM
          TAD I CA          /2ND BYTE
          ISZ CA
          JMS OUTPUT
          AND C7400        /3RD BYTE
          CLL RTR
          RTR
          TAD TEM
          RTR
          RTR
          JMS OUTPUT
C7600,    7600
          ISZ WC
          JMP UNP
          JMP XIT

TEM,      0                /SOMEWHERE IN HANDLER
CA,       0
WC,       0
C7400,    7400
  
```

/PUSH AND POP OPERATORS  
 /THE ROUTINES CAN OPERATE ON DIFFERENT STACKS  
 /WHICH ARE POINTED TO BY THE ARGUMENT.  
 /CONVENTION IS THAT THE POINTER ALWAYS POINTS TO  
 /AN ELEMENT, UNLESS COUNT=0, THEN IT POINTS TO  
 /ITSELF.

/  
 / TAD (AC  
 / JMS PUSH  
 / STACK  
 / FULL RETURN, AC=0  
 / NORMAL RETURN, AC=0

/STACK, -21 /-MAX SIZE OF STACK=21(8)  
 / 0 /COUNTER OF ELEMENTS; 0=EMPTY  
 / . /POINTER, SET TO CURRENT LOC.  
 / 1 /FIRST ELEMENT  
 / 2; 3; 4.....0 (LAST ELEMENT)

0 /TEMP. POINTER  
 PUSH, .-.  
 DCA POPTM /SHARED LOCATION  
 TAD I PUSH /SAVE PTR  
 ISZ PUSH  
 DCA PUSH-1  
 TAD I PUSH-1 /STACK FULL?  
 ISZ PUSH-1  
 TAD I PUSH-1  
 SMA CLA  
 JMP I PUSH /YES, FULL RETURN  
 ISZ I PUSH-1 /COUNT+1  
 ISZ PUSH-1  
 ISZ I PUSH-1 /POINTER+1  
 TAD I PUSH-1  
 DCA PUSH-1 /POINTER FETCHED  
 TAD POPTM /DEPOSIT IN STACK  
 DCA I PUSH-1  
 ISZ PUSH  
 JMP I PUSH

/THE POP OPERATION FETCHES ONE WORD FROM THE  
/STACK.

Ø56  
(CONTINUED)

```
/      JMS POP
/      STACK          /POINTS TO STACK
/      EMPTY RETURN   /AC=Ø
/      NORMAL RETURN  /AC=ELEMENT

POPTM, Ø
      7777
Ø      /TEMP.POINTER

POP,  .-.
      TAD I POP
      DCA POP-1       /SET UP PTR TO STACK
      ISZ POP
      ISZ POP-1
      TAD I POP-1     /COUNT=Ø?BUF EMPTY?
      SNA SPA
      JMP I POP       /YES, EMPTY RET.
      TAD POP-2       /DECREMENT COUNT
      DCA I POP-1
      ISZ POP-1       /POINTS TO PTR
      TAD I POP-1
      DCA PUSH-1
      TAD I PUSH-1    /FETCH ELEMENT
      DCA POPTM
      TAD PUSH-1     /DECREMENT PTR
      TAD POP-2
      DCA I POP-1
      TAD POPTM      /EXIT WITH ELEMENT IN AC
      ISZ POP
      JMP I POP
```

/FILL A ROTATING BUFFER QUEUE  
 /FILLQ IS A ROUTINE THAT PUTS THE AC IN THE NEXT  
 /FREE LOC. IN THE BUFFER. THE CONCEPT IS THAT THE ROU-  
 /TINE CAN BE USED FOR VARIOUS BUFFERS. EACH BUFFER  
 /CARRIES ITS OWN ADMINISTRATION DATA.

```


/      JMS FILLQ
/      BUF          /ARG POINTS TO BUF BOOKKEEPER.
/      FULL RETURN  /AC=0 IF ELEMENT STILL ACCEPTED
/                  /AC UNEQ 0 IF NOT ACCEPTED
/      NORMAL RETURN /AC=0

      0            /SAVE SIZE
      0            /POINTER IN BUFBOOKKEEPER
      0            /SAVE AC
FILLQ,  .-.        /ENTER WITH THE ELEMENT IN THE AC
      DCA FILLQ-1  /SAVE AC
      TAD I FILLQ  /ARGUM. POINTS TO BUF
      ISZ FILLQ    /FOR RETURN
      DCA FILLQ-2
      TAD I FILLQ-2 /SAVE SIZE
      DCA FILLQ-3
      ISZ FILLQ-2
      TAD FILLQ-3  /AC=-SIZE+COUNT+1
      CIA
      TAD I FILLQ-2
      IAC
      SMA SZA
      JMP FILLQ3   /BUF FULL, AC NOT ACCEPTED
      SZA CLA
      ISZ FILLQ    /FOR NORMAL RETURN
      ISZ I FILLQ-2 /COUNT+1
      ISZ FILLQ-2
      ISZ FILLQ-2  /FOR PTR2
      ISZ I FILLQ-2 /PTR2+1
      TAD FILLQ-3  /-SIZE+PTR2>=0?
      CIA
      TAD I FILLQ-2
      SMA SZA CLA
      JMP FILLQ2   /NO, WRAP AROUND
FILLQ1, TAD I FILLQ-2 /YES, COMPUTE REAL ADDR
      TAD FILLQ-2  /PTR2+ 'PTR2'
      DCA FILLQ-3
      TAD FILLQ-1
      DCA I FILLQ-3 /DEP IN BUF
      JMP I FILLQ
FILLQ2, IAC
      DCA I FILLQ-2
      JMP FILLQ1   /PTR2=1
FILLQ3, CLA
      TAD FILLQ-1
      JMP I FILLQ
  
```



FILL A ROTATING BUFFER Q

Ø57



/RESET A ROTATING BUFFER QUEUE  
 /CLEAR THE BUFFER BY SETTING COUNT=0, AND MOVING POINTERS  
 /TO THEIR INITIAL POSITION.(SYMMETRICALLY)

```

/BUF, 16      /MAX. SIZE OF BUFFER; SPECIFIED HERE
/      0      /COUNTS # OF ELEMENTS IN BUF
/      1      /EMPTY POINTER(PTR1) SET TO FIRST ITEM
/      16     /FILL POINTER(PTR2) SET TO END OF BUF
/      ZBLOCK 16    /THE ACTUAL BUFFER AREA

0      /SAVE SIZE
0      /BUFPTR
CLRQ,  --.    /ENTER WITH AC=0
TAD I CLRQ   /GET POINTER TO BUFBOOKKEEPER
DCA CLRQ-1
ISZ CLRQ     /FOR RETURN
TAD I CLRQ-1 /SAVE SIZE
DCA CLRQ-2
ISZ CLRQ-1   /FOR COUNT=0
DCA I CLRQ-1
ISZ CLRQ-1
IAC          /PTR1=1
DCA I CLRQ-1
ISZ CLRQ-1
TAD CLRQ-2
DCA I CLRQ-1 /PTR2=SIZE
JMP I CLRQ

```

```

/FETCH THE NEXT ITEM FROM THE HEAD OF THE Q.
/   JMS MTQ
/   BUF           /POINTER TO BUFFER
/   EMPTY RETURN /AC=0
/   NORMAL RETURN /AC=ELEMENT
/MTQ STANDS FOR EMPTY-THE QUEUE

```

```



      0           /SAVE ELEMENT
      0           /BUF SIZE
      0           /POINTER IN BUFBOOKKEEPER
MTQ,  --.        /ENTER WITH AC=0
      TAD I MTQ   /PTR TO BUFBOOKKEEPER
      DCA MTQ-1
      TAD I MTQ-1 /SAVE SIZE
      DCA MTQ-2
      ISZ MTQ     /FOR RETURN
      ISZ MTQ-1
      CMA
      TAD I MTQ-1 /COUNT-1<0?
      SPA
      JMP MTQ1    /YES, BUF EMPTY
      DCA I MTQ-1 /COUNT=COUNT-1
      ISZ MTQ-1
      IAC        /COMPUTE REAL ADDRESS
      TAD I MTQ-1 /PTR1+'PTR1'+1
      TAD MTQ-1
      DCA MTQ-3   /SAVE
      TAD I MTQ-3 /FETCH THE ELEMENT
      DCA MTQ-3   /SAVE
      ISZ I MTQ-1 /PTR1=PTR1+1
      TAD I MTQ-1 /-PTR1+SIZE<0?
      CIA
      TAD MTQ-2
      SMA CLA
      JMP MTQ2    /YES, UPDATE PTR1
      IAC
      DCA I MTQ-1 /PTR1=1
MTQ2, TAD MTQ-3  /ELEMENT IN AC
      ISZ MTQ
      JMP I MTQ
MTQ1, CLA
      JMP I MTQ   /'EMPTY' RETURN

```

# EMPTY A ROTATING BUFFER QUEUE

Ø59

EXAMPLE:  
SIZE = 10(10)



060

/COMBINED ROTATING BUFFER OPERATORS,CROSS FIELD CALLABLE.  
 /TWO SUBROUTINES HAVE BEEN PUT TOGETHER IN ORDER TO  
 /SAVE SPACE. FILLQ PUTS AN ELEMENT INTO THE BUFFER,  
 /AND MTQ TAKES ONE FROM THE BUFFER. EACH BUFFER HAS ITS  
 /OWN ADMINISTRATION, WHICH MAKES THE ROUTINES USEFUL FOR  
 /MULTIPLE BUFFERS WITH EACH ITS OWN LENGTH AND CONTENTS.  
 /WHEN USING THE ROUTINE CROSS FIELD IT ASSUMES THE BUFFER  
 /IN THE FIELD OF CALL. THE ARGUMENT IS RELATIVE, SO THE  
 /ROUTINES CAN BE USED IN A RELOCATABLE ENVIRONMENT.  
 /POINTERS ARE ALSO RELATIVE.

/THIS IS WHAT THE BUFFER LOOKS LIKE:

/BUF, 16 /MAX. SIZE OF BUF. HERE THE BUF IS 16 LONG  
 / 0 /COUNTER OF ELEMENTS IN THE BUFFER  
 / 0 /'READ' POINTER, USED BY MTQ  
 / 0 /'WRITE' POINTER, USED BY FILLQ  
 / ZBLOCK 16 /THE ACTUAL BUFFER AREA  
 /NOTE THAT THE BUFFER SHOULD BE SET UP AS ABOVE.

/ TAD ELEMENT  
 / CIF MONFLD  
 / JMS I (FILLQ  
 / BUF-.  
 / BUFFER FULL RETURN/AC=0 MEANS THAT THE ELEMENT  
 / /HAS BEEN ACCEPTED (THE VERY LAST ONE)  
 / /AC=ELEMENT MEANS NOT ACCEPTED!  
 / NORMAL RETURN /AC=0

QSIZE, 0 /SIZE OF BUF SAVED HERE  
 QPTR, 0 /POINTER IN ADMINISTRATION OF BUFFER.  
 C6203, 6203

FILLQ, .-.  
 JMS SETFIL /INITIAL SETUP,COMMON FOR BOTH.  
 TAD I QPTR /BUFFER FULL?  
 CMA  
 TAD QSIZE /SIZE-COUNT-1  
 SPA  
 JMP FILLQR-1 /BUF FULL;AC NOT ACCEPTED  
 SZA CLA  
 ISZ FILLQ /BUF OK;NORMAL RETURN  
 ISZ I QPTR /COUNT+1  
 ISZ QPTR  
 JMS QWRAP /INCREMENT POINTER AND/OR WRAP  
 TAD QAC /DEPOSIT  
 DCA I QPTR  
 CLA

FILLQR, 0  
 JMP I FILLQ

```

SETFIL,  .-.          /COMMON SETUP
          DCA QAC
          TAD I FILLQ  /GET ARGUMENT
          TAD FILLQ    /MAKE ABSOLUTE
          DCA QPTR
          TAD I QPTR   /SAVE SIZE
          DCA QSIZE
          RDF          /FOR RETURN
          TAD C6203
          DCA FILLQR
          ISZ QPTR     /-> COUNT
          ISZ FILLQ    /-> ERROR RETURN
          JMP I SETFIL

```

```

/INCREMENT POINTER, AND TEST FOR END OF BUFFER.
/ELSE WRAP-AROUND. RETURN WITH QPTR POINTING TO THE ABSOLUTE
/BUFFER LOCATION

```

```

QWRAP,  .-.
          ISZ QPTR     /ALSO COMMON INSTRUCTION
          ISZ I QPTR   /TRY NEXT LOC. IN BUF
          TAD QSIZE    /BEYOND SIZE?
          CIA
          TAD I QPTR
          SMA CLA
          DCA I QPTR   /WRAPS AROUND
QWR1,   TAD I QPTR    /COMPUTE ABSOLUTE ADDRESS
          TAD QPTR
          IAC
          DCA QPTR
          JMP I QWRAP

```

```

/FETCH THE NEXT ITEM FROM THE ROTATING BUFFER
/   CIF MONFLD
/   JMS I (MTQ
/   BUF-.
/   EMPTY RETURN  /AC=0
/   NORMAL RETURN /AC=ELEMENT

```

```

QAC=.          /TO SAVE SPACE
MTQ,  .-.
          TAD MTQ
          DCA FILLQ
          JMS SETFIL   /DO COMMON SETUP
          CMA
          TAD I QPTR   /COUNT-1<0?
          SPA
          JMP FILLQR-1 /Y, BUF EMPTY
          ISZ FILLQ    /FOR NORMAL RETURN
          DCA I QPTR   /N, CONFIRM
          JMS QWRAP    /INC POINTER ETC.
          ISZ QPTR     /READ POINTER COMES EARLIER.
          TAD I QPTR   /FETCH
          JMP FILLQR

```

```

/BINARY LOADER SUBROUTINE
/THIS BINARY LOADER IS MUCH DIFFERENT FROM THE STANDARD
/ONE . IT WAS DESIGNED ON THE CONCEPT OF A MECHANISM
/THAT FREES THE PROGRAMMER FROM THE CUMBERSOME BINARY
/FORMAT PECULIARITIES.THE PROGRAM READS BINARY 'TAPE'
/FROM AN INPUT DEVICE AND PRODUCES 3 PARAMETERS OF
/INTEREST:THE LOAD POINTER 'BINPC', THE LOAD FIELD 'BINFLD'
/AND THE CONTENTS OF THE DATA 'BINAC'. THE USER CAN
/TEST FORMATS AND BOUNDARIES, AND HAS TO DEPOSIT THE
/DATA HIMSELF.
/DURING LEADER PHASE THE ROUTINE IGNORES BOTH LEADER
/AND BLANK CODE. A JMS TO BINL WITH AC UNEQ 0 ALSO
/RESETS ALL PARAMETERS AND RETURNS TO LEADER MODE.

```

```

/THE BINARY FORMAT TAPE HAS 3 PHASES:
/PHASE 1 (LEADER PHASE) CODES 200 OR 000
/PHASE 2 (ORIGINS, DATA AND FIELD SETTINGS)
/      3X0      /FIELD SETTING TO FIELD X;ADDS NOT TO CHECKSUM
/      2XX;0YY /ORIGIN SETTING TO PC=XXYY; ADDS TO CHECKSUM
/      0XX;0YY /DATA ELEMENTS XXYY;ADD TO CHECKSUM
/      0XX;0YY /CHECKSUM XXYY,RIGHT BEFOR THE STOP SIGN
/PHASE 3 (THE STOP SIGN) IS ALSO ONE 200 CODE

```

/HOW TO USE THE ROUTINE AS A STANDARD BINARY LOADER

```

/START, JMS BINL
/      HLT /EOT RETURN;AC=0
/      HLT /READY RETURN;AC=DIFFERENCE IN CHECKSUMS
/      TAD BINFLD      /AC=0;NORMAL RETURN
/      DCA TEM
/      TAD BINAC
/TEM, 0
/      DCA I BINPC
/      JMP START

```

```

-100
-300      /CONSTANTS
6201
-200

```

```

BINCL, 77      /MASK
BINPH, 0      /PHASE FLAG.0=LEADER, POS=ORIGIN;NEG=DATA
BINPC, 0      /LOAD POINTER
BINAC, 0      /DATA TO BE DEPOSITED IN LOADPOINT
BINFLD, 0     /FIELD INTO WHICH TO LOAD
CHKSUM, 0     /COMPUTED CHECKSUM
CHKTEM, 0     /CHECKSUM OVER 2 FRAMES
0        /FRAME 2
0        /FRAME 1

```

```

BINL,  --.      /AC UNEQ TO 0 RESET ALL PARAMETERS
      SZA CLA
      JMP BIN3
BIN2, TAD BINPH /ARE WE IN LEADER PHASE?
      SNA CLA
      JMP BIN3      /Y

```

```

BIN4,   TAD BINL-1      /N, IS FRAME1=FIELD?
        TAD BINC-3      /-300
        SMA CLA
        JMP BIN6        /Y, SET FIELD
        TAD BINL-1      /IF 100-177 MAKE PHASE GT 0
        TAD BINC-4      /IF 000-077 MAKE PHASE NEG
        SMA
        IAC            /TO AVOID AC=0
        DCA BINPH

/ASSEMBLE 6 M.S.BITS IN BINAC AND MAKE TEMP.CHECKSUM
        TAD BINL-1
        AND BINC
        CLL RTL
        RTL
        RTL
        DCA BINAC
        TAD BINL-1      /MAKE TEMP CHKSUM
        DCA CHKTEM

/READ FRAME 2
        JMS HSREAD
        JMP BINRET+1 /EOT RETURN
        DCA BINL-2

/ASSEMBLE 6 L.S. BITS AND UPDATE TEMP.CHECKSUM
        TAD BINL-2
        AND BINC
        TAD BINAC
        DCA BINAC
        TAD BINL-2      /TEMP CHKSUM
        TAD CHKTEM
        DCA CHKTEM
        TAD BINPH      /ARE WE IN ORIGIN PHASE?
        SMA CLA
        JMP BIN7        /Y;PROCESS ORIGIN SETTING

/READ FRAME 1 IN ADVANCE; THIS IS FOR DATA ONLY
        JMS HSREAD
        JMP BINRET+1 /EOT RETURN
        DCA BINL-1
        TAD BINL-1
        TAD BINC-1      /IS IT 200 CODE?(STOP COE)
        SNA CLA
        JMP BIN8        /Y,END OF DATA
        ISZ BINPC      /NEXT LOCATION
        NOP            /JUST IN CASE
        TAD CHKTEM      /UPDATE CHKSUM
        TAD CHKSUM
        DCA CHKSUM
        ISZ BINL
BINRET, ISZ BINL
        JMP I BINL

```



/RESET ALL PARAMETERS FOR START OF NEW DATATAPE

```
BIN3,  TAD BINC-2      /CDF 0
        DCA BINFLD
        DCA CHKSUM     /CHKSUM=0
        DCA BINPH      /SET TO LEADER PHASE

BIN5,  JMS HSREAD      /READ 1 FRAME
        JMP BINRET     /EOT RETURN
        DCA BINL-1
        TAD BINL-1     /IS IT LEADER CODE?
        TAD BINC-1
        SNA CLA
        JMP BIN2       /Y, PROCEED LEADER LOOP
        TAD BINL-1     /IS IT 000?
        SNA CLA
        JMP BIN2       /Y, IGNORE ALSO IF IN LEADER MODE
        JMP BIN4       /N, CAN BE ORIGIN ONLY
```

/MAKE CDF OUT OF FRAME 1

```
BIN6,  TAD BINL-1
        AND BINC
        TAD BINC-2     /AC=0X0
        DCA BINFLD
        JMP BIN5
```

/PROCESS ORIGIN SETTING AND LOOK FOR MORE


```
BIN7,  CMA            /PC-1
        TAD BINAC      /THIS IS NEW PC
        DCA BINPC
        TAD CHKTEM
        TAD CHKSUM     /UPDATE CHKSUM
        DCA CHKSUM
        JMP BIN5
```

/END OF DATA PROCESSING; COMPARE TWO CHECKSUMS

```
BIN8,  DCA BINPH      /SET TO LEADER PHASE
        TAD BINAC      /TAPE CHKSUM
        CIA
        TAD CHKSUM
        JMP BINRET     /END OF DATA RETURN(READY)
```

# BINARY LOADER SUBROUTINE

Ø61



```

/INTERRUPT SERVICE BY LIST LOOK-UP
/THE ROUTINE TRIES TO IDENTIFY THE INTERRUPTING
/DEVICE BY LOOKING IN THE SKIP LIST. IF FOUND, IT
/CLEAR THE HARDWARE FLAG WITH THE INSTRUCTION
/IN THE CLEARLIST. THEN IT JUMPS TO THE LOCATION
/POINTED TO IN THE JUMP LIST.
/IT TAKES CARE FOR SPECIAL DEVICES THAT SKIP IF THE
/FLAG WAS LOW INSTEAD OF HIGH, AS IS NORMALLY THE CASE.
/THIS IS NECESSARY FOR THE K08 INTERRUPTBAR.(6051)
/FOR THIS PURPOSE LEAVE OUT BIT 4000(2051) IN SKIPLST.
/SKIP LIST ALWAYS TERMINATED BY A ZERO!!!!
/OTHER LISTS NOT.

```

```

/SKPLST,          6031;6041;2051;6141;6151;0
/CLRLST,          6032;6042;6052;6142;6152
/JMPLST,          KBD1;TTY;INTBAR;KBD2;TTY2
/

```

```

/*0      JMP I .+1;INTSERV

```

```

INTAC,  0          /AC SAVED HERE
INTLNK, 0          /LINK SAVED HERE
INTPTR, 0          /POINTER IN LISTS
          4000
          SKPLST-1
          CLRLST-SKPLST /USED TO FIND LIST
          JMPLST-CLRLST /TO FIND JUMPLIST

```

```

INTSERV, DCA INTAC /SAVE AC AND LINK
          RAL
          DCA INTLNK
          TAD INTSER-3 /SET UP POINTER
          DCA INTPTR

```

```

INT1,   CLA          /JUST IN CASE
          ISZ INTPTR
          TAD I INTPTR /GET SKIP INSTR.
          SMA          /STRANGE SKIP?
          JMP INT2     /YES, BIT 4000 WAS LEFT OUT
          DCA .+1
          0           /OVERLAID BY SKIP INSTR.
          JMP INT1     /DID NOT SKIP

```

```


INT3,   TAD INTPTR
          TAD INTSER-2 /WHERE IS CLEAR INSTR?
          DCA INTPTR
          TAD I INTPTR /PICK IT UP
          DCA .+1
          0           /OVERLAID BY CLEAR INSTR.
          TAD INTPTR  /WHERE TO GO?
          TAD INTSER-1
          DCA INTPTR
          TAD I INTPTR
          DCA INTPTR
          JMP I INTPTR /JUMP THERE

```

INT2,	SNA	/END OF LIST?
	HLT	/HALT IF INTERRUPT NOT FOUND
	TAD INTSER-4	/SET BIT 4000
	DCA .+1	
	Ø	/OVERLAID BY SKIPINSTR.
	JMP INT3	
	JMP INT1	
EXIT,	CLA CLL	/JUST IN CASE
	TAD INTLNK	
	CLL RAR	
	TAD INTAC	
	RMF	
	ION	
	JMP I Ø	

# GENERAL INTERRUPT BRANCHER

Ø62



/FIND SMALLEST HOLE IN A LIST, JUST BIG ENOUGH.  
 /THE ROUTINE FINDS A HOLE IN A LIST THAT MATCHES  
 /A SPECIFIED SIZE (IN THE AC) BEST. IT RETURNS  
 /WITH THE POINTER TO THAT HOLE IN THE AC.

/ TAD (4                    /SEARCH SMALLEST HOLE > OR = 4LOC.  
 / JMS SMALL  
 / LISTBEGIN  
 / -LISTEND  
 / NOT FOUND RETURN            /AC=0  
 / NORMAL RETURN            /AC=POINTER TO HOLE BEGIN

/LISTBEGIN,            1;3;2;4;0;0;0;0;0  
 /LISTEND,            0  
 /ZER0ES REPRESENT HOLES!!!!

SMALCN,            7777                    /ENDSWITCH:0=END;7777=NORMAL  
                   0                    /COUNTS SIZE OF HOLE  
                   0                    /POINTS WHERE LAST HOLE WAS  
                   0                    /HOLEFLAG:0=HOLE;7777=NOT HOLE  
                   0                    /POINTER IN LIST  
                   0                    /SIZE OF LAST HOLE  
                   0                    /-SIZE OF HOLE WANTED.

SMALL,            .-.                    /ENTRY, SIZE OF WANTED HOLE IN AC  
                   CIA  
                   DCA SMALL-1            /SAVE -SIZE  
                   CMA                    /SET LAST HOLE SIZE TO LARGE VALUE  
                   DCA SMALL-2  
                   CMA                    /RESET END SWITCH  
                   DCA SMALCN-1  
                   CMA  
                   TAD I SMALL            /SET UP POINTER (-1)  
                   DCA SMALL-3  
                   ISZ SMALL            /POINTS TO -LISTEND)  
 SMAL1,            DCA SMALCN            /CLEAR HOLE COUNTER  
                   CMA                    /SET HOLEFLAG TO NOT HOLE  
 SMAL2,            DCA SMALL-4  
                   TAD SMALCN-1            /END SWITCH SET?  
                   SNA CLA  
                   JMP SMALND            /YES, REAL END  
                   TAD SMALL-3            /OUT OF LIST?  
                   CLL  
                   TAD I SMALL  
                   SZL CLA  
                   JMP SMAL5            /YES, SIGNAL END FOR NEXT TURN  
                   ISZ SMALL-3            /POINTER+1  
                   TAD I SMALL-3            /FETCH

/THE FOLLOWING INSTRUCTION DETERMINES WHAT IS A HOLE  
 /AND WHAT NOT. IN THIS CASE : 0000='HOLE'  
                   SZA CLA            /IS IT A ZERO?  
                   JMP SMAL3            /NO  
                   DCA SMALL-4            /CLEAR HOLEFLAG  
                   ISZ SMALCN            /COUNT SIZE OF HOLE  
                   JMP SMAL2            /SET HOLEFLAG AND PROCEED

```

/WE HAVE NOW TOUCHED AN OCCUPIED LOCATION. IF THIS
/WAS THE FIRST AFTER A SET OF ZEROES, IT TERMINATES
/A HOLE. LISTEND ALSO TERNINATES A HOLE!!(ENDFLAG)
SMAL3, TAD SMALL-4      /HOLEFLAG=0?
      SZA CLA
      JMP SMAL1         /NO, WE ARE STILL IN OCC. AREA
      TAD SMALCN       /YES, WE JUST ISOLATED A HOLE
      TAD SMALL-1     /IS HOLE EXACTLY WHAT WE WANT?
      SNA
      DCA SMALCN-1    /SET END FLAG
      SPA CLA
      JMP SMAL1         /NO, TOO SMALL, SEARCH FURTHER
      TAD SMALL-2     /YES, FOUND A POSSIBLE HOLE
      CIA CLL         /IS IT SMALLER THAN LAST HOLE?
      TAD SMALCN
      SZL CLA
      JMP SMAL1         /NO, LAST HOLE IS BETTER MATCH
      TAD SMALCN       /YES, REPLACE LAST HOLE
      DCA SMALL-2
      TAD SMALL-2     /MAKE IT POINT TO HOLEBEGIN
      CIA
      TAD SMALL-3     /ALSO REMEMBER WHERE LAST HOLE BEGINS
      DCA SMALL-5
      JMP SMAL1

```

```

/END OF LIST DETECTED, MAY TERMINATE A SET OF ZEROES (HOLE)
/SO SET FLAG TO SIGNAL THAT THE GAME IS OVER, BUT PROCESS
/THE HOLE FIRST.

```

```

SMAL5, DCA SMALCN-1    /SET END FLAG
      JMP SMAL3

```

```

/END OF THE ROUTINE. THERE IS EITHER A HOLE OR NO
/HOLE FOUND(LASTHOLE IS STILL 7777)


```

```


SMALND, TAD SMALL-2    /LASTHOLE=7777?
      CMA
      SNA CLA
      JMP SMAL4+1      /YES, NOTHING FOUND
      TAD SMALL-5     /TAKE PCINTER IN AC
SMAL4, ISZ SMALL
      ISZ SMALL
      JMP I SMALL

```

FIND THE SMALLEST HOLE IN A LIST, GREATER THAN OR EQUAL TO THE VALUE IN THE AC.







/LINK FOR RELOCATABLE CROSS-PAGE REFERENCING; WITHIN 1 FIELD.  
 /THIS LINK WORKS IN MUCH THE SAME WAY AS A DEBUGGING TRACER.  
 /IT EXECUTES THE INSTRUCTION WITH A COMPUTED OPERAND.  
 /THE ROUTINE HAS BEEN TAILORED FOR AND, TAD, ISZ, DCA,  
 /JMP AND JMS. THE LINK WILL BE PRESERVED AND OPERATED  
 /UPON IN THE NORMAL WAY. IN CASE OF A JMS THE ABSOLUTE  
 /RETURN ADDRESS IS DEPOSITED IN THE SUBROUTINE ENTRY,  
 /SO THAT THE RETURN FROM THE SUBROUTINE IS THROUGH A  
 /JMP I SUBR. ENTRY. ARGUMENTS ARE PICKED UP IN THE SAME WAY:  
 /TAD I SUBR. ENTRY.

/ TAD AC  
 / JMS LINK /LINK PREFERABLY IN PAGE 0  
 / B- /RELATIVE POINTER  
 / TAD /OR AND, ISZ, DCA, JMP, JMS  
 / RETURN  
 / RETURN IF ISZ SKIPPED

1000 /CONSTANT  
 AND I LINKPC /TO MAKE REAL INSTRUCTION FROM  
 LINKPC, 0 /COMPUTED ABSOLUTE ADDRESS  
 LINKAC, 0 /SAVED AC

LINK, .-.  
 DCA LINKAC  
 TAD I LINK /COMPUTE OPERAND(PC)  
 SPA /TO PRESERVE THE LINK  
 CML  
 TAD LINK /MAKE ABSOLUTE ADDRESS  
 DCA LINKPC  
 ISZ LINK  
 TAD I LINK /AND, TAD...ETC  
 ISZ LINK  
 SPA  
 JMP LINKJ /JMP OR JMS  
 TAD LINKPC-1 /MAKE TAD I LINK INSTR ETC.  
 DCA .+2  
 TAD LINKAC  
 0 /OVERLAID  
 JMP I LINK /NORMAL RETURN  
 ISZ LINK /IF IT SKIPPED, RETURN+1  
 JMP I LINK

LINKJ, AND LINKPC-2 /AND (1000  
 SZA CLA /IS IT JMP OR JMS?  
 JMP LINK3 /JMP  
 TAD LINK /DEP. 'RETURN' IN SUBR. ENTRY  
 DCA I LINKPC  
 ISZ LINKPC /JUMP TO SUBR.ENTRY+1

LINK3, TAD LINKAC  
 JMP I LINKPC

DYNAMIC CORE STORAGE ALLOCATION

065-072

\*\*\*\*\*


ONE OF THE METHODS TO ALLOCATE CORE STORAGE DYNAMICALLY IS BY USING THE 'FREE-CORE' TECHNIQUE. FREE-CORE IS AN AREA IN CORE, DIVIDED INTO BLOCKLETS OF A GIVEN SIZE. (ALSO EQUAL IN SIZE) THESE BLOCKLETS CONTAIN ONE POINTER POINTING TO THE FOLLOWING BLOCKLET, IN THIS WAY LINKING THE BLOCKLETS IN ONE DIRECTION. (FIG 1)

IF A PROGRAM (1) REQUIRES CORE STORAGE FOR VARIABLES, DATA, OR PUSH-DOWN LISTS, THE NECESSARY STORAGE CAN BE REQUESTED FROM FREECORE IN UNITS OF A GIVEN SIZE. (ONE BLOCKLET AT A TIME). (FIG 2)

IF, FOR EXAMPLE, A DIFFERENT PART OF THE PROGRAM REQUIRES 2 BLOCKLETS, THE FREECORE AREA CAN BE AS IN FIGURE 3.

IF PROGRAM (1) NO LONGER NEEDS ITS BLOCKLET, IT CAN RELEASE THAT BLOCKLET TO FREECORE, WHICH RESTORES THE CHAIN AS IN FIGURE 4.

THE ROUTINES DESCRIBED IN THE FOLLOWING PAGES MAKE USE OF A FREE-CORE AREA CONTAINING BLOCKLETS OF 8 COMPUTER WORDS, THE LAST WORD IN EACH BLOCKLET IS RESERVED FOR THE POINTER.



065

/INITIALIZE THE FREECORE AREA  
/IT ACTS AS IF ALL THE BLOCKS WERE OCCUPIED BY  
/SOME STRANGE CHAIN. BY RELEASING THE BLOCKS ONE  
/AFTER ANOTHER, THEY BECOME CHAINED TO THE FREE-  
/CORE CHAIN OF AVAILABLE BLOCKS. FC ZEROED FIRST.  
/FREELO AND FREEHI DELIMIT THIS ACTION.

/  
/           CLA  
/           JMS INITFC  
/           NORMAL RETURN

INITFC, 0                    /TEMP. STORAGE  
          .--  
          DCA FREEF            /NO FREEBLKS AVAILABLE  
          DCA FREECT  
          TAD FREEHI           /GET UPPER LIMIT OF FREECORE  
          DCA INITFC-1

/  
AGAIN, TAD INITFC-1            /RELEASE ALL BLOCKS  
          JMS RELBLK            /AND CHAIN ALL TOGETHER  
          TAD INITFC-1  
          TAD C7770            /SET UP FOR NEXT BLOCK  
          DCA INITFC-1

/  
          TAD FREELO           /GET LOWER LIMIT OF FREECORE  
          CIA  
          TAD INITFC-1        /THIS BLOCK BELONGS TO FREECORE?  
          SMA CLA            /SKIP IF NO  
          JMP AGAIN           /YES, RELEASE THIS BLOCK AND SO ON  
/  
          JMP I INITFC        /RETURN

066

```

/REQUEST A FREE BLOCK
/THE ROUTINE ISOLATES A BLOCK FROM THE TAIL OF THE
/CHAIN OF FREE CORE BLOCKS, AND LINKS IT TO THE BLOCK,
/POINTED TO BY THE AC. IF THE AC=0 NO LINK IS MADE
/THIS IS FOR THE VERY FIRST REQUEST.
/IN CASE OF ERROR RETURN: AC=0; ELSE AC
/POINTS TO FIRST LOC OF REQUESTED NEW BLK.
/
/      TAD (ANY LOC. IN PREVIOUS BLOCK, OR AC=0
/      CIF 0
/      JMS REQBLK
/      ERROR RETURN /NO MORE BLKS AVAILAELE
/      NORMAL RETURN

```

```

REQBLK= 0 /TEMPORARY STORAGE
RELK,   .-.
DCA RELK-1 /SAVE
RDF
TAD C6203
DCA RBLRET
CDF 0
TAD RELK-1
SNA
JMP RELK2
AND C7770 /MAKE POINTER TO LINK LOCATION.
TAD C7
DCA RELK-1
TAD FREEF /POINTS TO TAIL
SNA
JMP RBLRET /0 = NO BLKS AVAILABLE
DCA I RELK-1 /MAKE LINK TO NEW BLK
RELK2. TAD FREEF /FIND NEW TAIL
SNA
JMP RBLRET /NO MORE BLKS AVAILABLE
TAD C7
DCA RELK-1
TAD I RELK-1 /UPDATE FREEFIRST (THE TAIL)
DCA FREEF
DCA I RELK-1 /ZERO THE LINK OF REQ BLK
CMA
TAD FREECT /DECREMENT THE NUMBER OF AVAILAELE FREE
DCA FREECT /BLOCKS
TAD RELK-1 /TAKE POINTER TO REQ BLK
AND C7770 /FST LOC OF ELK
ISZ RELK
RBLRET. 0
JMP I RELK /NORMAL RETURN.

```

/RELEASE A BLOCKLET TO FREECORE.  
 /THE BLOCK POINTED TO BY THE AC. IS LINKED TO THE  
 /TAIL OF THE CHAIN OF FREE CORE BLOCKS WITH ITS  
 /CONTENTS ZEROED.  
 /EXIT IS ALWAYS WITH AC =0. THERE IS NO ERROR EXIT.

067

/ TAD (POINTER  
 / CIF 0  
 / JMS RELBLK  
 / NORMAL RETURN/AC=0

RELBLK=.

RLRL,     . --.  
           AND C7770            /KILL BIT 9-11  
           TAD C7                /INSERT BIT 9-11  
           DCA RBLK            /SAVE TEMP  
           RDF  
           TAD C6203  
           DCA RLRETR  
           CDF 0  
           TAD FREEF            /GET ADDR. OF NEXT FREE FREEBLK  
           DCA I RBLK         /CHAIN THIS BLOCK TO THE  
                               /FREE CHAIN  
           TAD RBLK  
           AND C7770            /SET UP ADDR. OF THIS BLOCK  
           DCA FREEF            /STORE AT PAGE 0  
           TAD M7               /SET UP COUNTER  
           DCA RBLK-1  
           TAD FREEF            /GET ADDR. OF FIRST WORD IN BLOCK  
           DCA RBLK  
           DCA I RBLK  
           ISZ RBLK  
           ISZ RBLK-1            /INCR. COUNT  
           JMP .-3               /AGAIN IF CNT NONZERO  
           ISZ FREECT           /INCR. NR. OF FREE BLOCKS  
 RLRETR, 0  
           JMP I RLRL           /RETURN

/RELEASE A Q OF FORWARD LINKED BLOCKLETS TO FC.

068

/ TAD (POINTER IN FIRST BLKLT  
/ CIF MONFLD  
/ JMS RELQ  
/ NORMAL RETURN /AC=0

0 /TEMPORARY  
0 /TEMPORARY

RELQ,     .-.  
DCA RELQ-1     /SAVE AC  
RDF           /MAKE RETURN  
TAD C6203  
CDF MONFLD  
DCA RELQF  
TAD RELQ-1  
RELQ2,   AND C7770     /MAKE -> FORWARD LINK  
TAD C7  
DCA RELQ-1  
TAD I RELQ-1   /PICK UP FORWARD LINK  
DCA RELQ-2  
TAD RELQ-1     /RELEASE THIS BLKLT  
JMS RELBLK  
TAD RELQ-2     /IF FORWARD LINK=0;END OF CHAIN  
SZA  
JMP RELQ2  
RELQB,     0  
JMP I RELQ

ø6g

```

/MAKE A BUFFER OR QUEUE IN FREECORE
/THE ROUTINE CREATES A 'BOOKKEEPING' BLOCK AND THE
/FIRST BLOCK OF THE BUFFERQUEUE. IT SETS THE PARA-
/METERS OF 'BOOK' ACCORDINGLY.
/THE CONTENTS OF THE AC IS USED TO SET THE MAXIMUM
/ALLOWABLE LENGTH OF THE BUFFER. RETURN IS WITH THE
/POINTER TO 'BOOK' IN THE AC. IN CASE OF ERROR RETURN
/(NO ROOM AVAILABLE),AC=0. AND THERE WILL ALSO BE NO
/'BOOK' BLOCK.

```

```

/      TAD (MAXIMUM LENGTH
/      CIF 0
/      JMS MAKQ
/      ERROR RETURN          /AC=0
/      NORMAL RETURN        /AC= PTR TO 'BOOK'

```

```

0          /TEMP. POINTER
0          /POINTS TO FST LOC IN BUF
0          /POINTS TO 'BOOK'
0          /'MAXIMUM'
MAKQ, 0
DCA MAKQ-1      /SAVE
EDF
TAD C6203
DCA MAKRET
CDF 0
TAD MAKQ-1
SNA          /CHECK FOR AC=0
JMP MAKRET     /ERROR AC=0
DCA MAKQ-1     /SAVE
JMS REQBLK     /REQ. 'BOOK' BLK
JMP MAKRET     /NO ROOM; ERROR
DCA MAKQ-2     /SAVE 'BOOK' PTR
TAD MAKQ-2     /REQ. FIRST BUF BLK
JMS REQBLK
JMP MAKQ2      /NOT AVAILABLE
DCA MAKQ-3     /SAVE PTR TO FST BUFBLK

```

/THE 'BOOK' BLK IS SET UP AS FOLLOWS:

```

/BOOK, 0          /'DATA'
/      BUFPTR+1    /'BUFTAIL'
/      0           /'BUFCOUNT'
/      BUFPTR      /'BUFHEAD'
/      MAXIMUM
/      0
/      0
/      0

```



```

TAD MAKQ-2      /SET UP TEMP PTR
DCA MAKQ-4
ISZ MAKQ-4      /POINTS 'BUFTAIL'
TAD MAKQ-3
IAC
DCA I MAKQ-4
ISZ MAKQ-4      /SET UP 'BUFHEAD'
ISZ MAKQ-4
TAD MAKQ-3
DCA I MAKQ-4
ISZ MAKQ-4      /SET UP 'MAXIMUM'
TAD MAKQ-1
DCA I MAKQ-4
TAD MAKQ-2      /EXIT WITH PTR TO 'BOOK' IN AC
ISZ MAKQ
MAKRET, 0
JMP I MAKQ

MAKQ2, TAD MAKQ-2      /IF NO ROOM, RELEASE 'BOOK' BLK TOO
JMS RELEBLK
JMP MAKRET

```

070

```

/READ NEXT ELEMENT FROM THE TAIL OF A BUFFER.
/THE AC MUST POINT TO A SECTION IN CORE WHERE THE
/BOOKKEEPING OF THIS BUFFER IS DONE. FORMAT IS:
/BOOK, DATA /TEMP. SAVE LOCATION, ONE ELEMENT
/ BUFTAIL /TAIL OF BUFFER, FIRST LOC.
/ BUFCOUNT /# OF ELEMENTS NOW IN BUF
/ BUFHEAD /HEAD OF BUFFER, LAST LOC.
/ MAXIMUM /MAX # OF ELEMENTS ALLOWED

```

```

/ TAD (BOOK
/ CIF 0
/ JMS RBUF
/ BUF EMPTY RET. AC=0
/ RETURN WITH ELEMENT IN AC.

```

```

0 /TEMPORARY
0 / "

```

```

RBUF=.
RB, 0
DCA RB-1 /SAVE POINTER TO BOOK
RDF
TAD C6203
DCA RRET
CDF 0
CLL CML RTL /AC=2
TAD RB-1
DCA RB-2 /POINTS TO BUFCOUNT
TAD I RB-2 /IS BUF EMPTY?
SNA
JMP RRET /YES, ERROR RETURN
TAD M1 /NO, COUNT-1
DCA I RB-2
ISZ RB-1 /POINTS TO BUFTAIL
TAD I RB-1 /IS THIS THE LINK?
DCA RB-2
TAD I RB-1
AND C7
TAD M7
SZA CLA
JMP RB2 /NO
TAD I RB-2 /YES, GET LINK TO NXT BLK.
DCA I RB-1 /UPDATE BUFTAIL
TAD RB-2 /NOW RELEASE BLOCK
JMS RELBLK
RB2, TAD I RB-1 /FETCH ELEMENT
DCA RB-2
ISZ I RB-1 /BUFTAIL+1 FOR NXT ENTRY
TAD I RB-2
ISZ RB
RRET, 0
JMP I RB

```

WRITE AN ELEMENT ONTO THE TOP OF A BUFFERQUEUE  
 IN FREECORE. BUF FULL RETURN IS TAKEN  
 WHEN BUFFER FULL OR NO FREE BLOCKS AVAILABLE.  
 BUF FULL RET IS ALSO TAKEN WHEN THE LAST CHAR  
 COULD JUST BE STORED. SUCCESSIVE ATTEMPTS LOSE DATA.

TAD ELEMENT /STORE IN 'DATA'  
 CIF 0  
 JMS WBUF  
 BOOK /POINTER TO BOOK BLK, FLD0  
 BUF FULL RETURN /AC=0; ALSO IF F.C. FULL  
 NORMAL RETURN /AC=0

0 /FLAG; -1 IF LAST ELEMENT  
 0 /DATA STORE  
 0 /TEMPORARY  
 0 / "

WB,

0  
 DCA WB-3  
 TAD I WE /PICK UP BOOKPTR  
 DCA WE-1  
 ISZ WB  
 RDF  
 TAD C6203  
 DCA WRET  
 CDF 0  
 ISZ WE-1  
 ISZ WE-1 /POINTS TO 'BUFCOUNT'  
 CLL CML RTL /AC=2  
 TAD WB-1  
 DCA WE-2 /POINTS TO 'MAXIMUM'  
 TAD I WE-2 /BUF FULL?  
 CIA  
 TAD I WE-1  
 SMA  
 JMP WRET /YES, ERROR  
 DCA WB-4 /FLAG FOR LAST ELEMENT  
 TAD WB-1  
 IAC  
 DCA WB-2 /POINTS TO 'BUFHEAD'  
 ISZ I WE-2 /BUFHEAD+1 GIVES NXT FREE LOC.  
 TAD I WE-2 /IS THIS THE LINK?  
 AND C7  
 TAD M7  
 SZA CLA  
 JMP WB2 /NO  
 TAD I WE-2 /YES, REQUEST A FREE BLK  
 JMS REOBLK  
 JMP WRET /NO ROOM; ERROR; AC=0  
 DCA I WE-2 /UPDATE BU 'BUFHEAD'  
 TAD I WE-2 /PUT DATA IN BUF  
 ISZ I WE-1 /BUFCOUNT+1  
 DCA WB-2  
 TAD WB-3  
 DCA I WE-2  
 ISZ WB-4 /ERR. RET. IF LAST ELEMENT  
 ISZ WB /NORMAL RET

WE2,

WRET,

0  
 JMP I WE

/KILL THE BUFFER QUEUE  
/THIS OPERATION, WHICH MAY BE TIME-CONSUMING, RELEASES  
/ALL THE BUFFERBLKS TO FREECORE, ALSO THE 'BOOK' BLK.

/ TAD (POINTER TO 'BOOK'  
/ CIF 0  
/ JMS KILLQ  
/ NORMAL RETURN /AC=0

0 /TEMP. LINK  
0 /POINTS LINK OF THIS BLK  
0 /POINTS IN 'BOOK'

KILLQ, 0  
DCA KILLQ-1 /SAVE  
RDF  
TAD C6203  
DCA KILLRT  
CDF 0  
ISZ KILLQ-1 /POINTS 'BUFTAIL'  
TAD I KILLQ-1  
AND C7770

KILLQ2, TAD C7 /POINTS TO LINK  
DCA KILLQ-2  
TAD I KILLQ-2 /GET LINK  
DCA KILLQ-3  
TAD KILLQ-2 /NOW RELEASE BLK  
JMS RELELK  
TAD KILLQ-3 /WAS IT LAST BLK OF QUEUE?  
SZA  
JMP KILLQ2 /NO, SEARCH NEXT  
TAD KILLQ-1 /YES, KILL 'BOOK' TOO  
JMS RELBLK

KILLELT, 0  
JMP I KILLQ

```

/ROUTINES TO CONVERT OCTAL NUMBERS 0-17
/TO EXCESS 40 STRIPPED CODE
/
/INPUT OCTAL
/OUTPUT OCTAL
/
/EXAMPLE:15 --> 2125
/          07 --> 2027
/
      TAD M10
      SMA
      TAD C70
      TAD C2030
/*****
/INPUT OCTAL
/OUTPUT OCTAL
/LEADING ZERO'S BECOME PACKED SPACES
/
/EXAMPLE:15 --> 2125
/          07 --> 0027
/
      TAD M10
      SMA
      TAD C2070
      TAD C30
/*****
/INPUT OCTAL
/OUTPUT DECIMAL
/
/EXAMPLE:15 --> 2123
/          07 --> 2027
/
      TAD M12
      SMA
      TAD C66
      TAD C2032
/*****
/INPUT OCTAL
/OUTPUT DECIMAL
/LEADING ZERO'S BECOME PACKED SPACES
/
/EXAMPLE:15 --> 2123
/          07 --> 0027
/
      TAD M12
      SMA
      TAD C2066
      TAD C32
/*****
/GENERAL CONSTANTS:
/
M10,    -10
M12,    -12
C30,     30
C32,     32
C66,     66
C70,     70
C2030,  2030
C2032,  2032
C2066,  2066
C2070,  2070
/

```

074

```
/INTERRUPT ROUTINE FOR REALTIME CLOCK
/
/TIME AND DATE ARE AVAILLABLE IN REGISTERS
/   MIN
/   HOUR
/   DAY
/   MONTH
/   YEAR
/
/OPTIONAL DAY OF WEEK AVAILLABLE IN REGISTER
/   DAYW   1=SUNDAY
/           2=MONDAY
/           ETC.
/
/ENTRY AFTER CLOCK INTERRUPT
/WITH AC AND LINK SAVED
/
CLOCK, ISZ TICK
      JMP EXIT           /RETURN FROM INTERRUPT
      TAD M50           /50 HERTZ
      DCA TICK         /RESET TICK = -50
      ISZ SEC
      JMP EXIT
      TAD M60
      DCA SEC         /RESET SEC = -60
      ISZ MIN
      TAD MIN
      TAD M60         /60 MINUTES GONE?
      SZA CLA
      JMP EXIT        /NO
      DCA MIN        /YES, RESET MIN = 0
      ISZ HOUR
      TAD HOUR
      TAD M24
      SZA CLA        /24 HOURS GONE?
      JMP EXIT        /NO
      DCA HOUR        /YES, RESET HOUR = 0
      ISZ DAY
      TAD DAYW
      IAC             /*****
                     /*IF DAY OF WEEK IS
      AND C7          /*NOT IMPORTANT DELETE
      SNA             /*THESE INSTRUCTIONS
      IAC             /*
      DCA DAYW        /*****
      TAD MONTH
      TAD MONLST     /# OF DAY / MONTH
      DCA TEMP
      TAD DAY
      TAD I TEMP
      SPA SNA CLA    /LAST DAY OF MONTH?
      JMP EXIT
```

```

IAC /YES
DCA LAY /RESET DAY = 1
ISZ MONTH
TAD MONTH
TAD M12
SPA SNA CLA /LAST MONTH OF YEAR?
JMP EXIT
IAC /YES
DCA MONTH /RESET MONTH = 1
ISZ YEAR
TAD YEAR
AND C3
SZA CLA /IS IT A LEAPYEAR?
JMP NLY /NO LEAPYEAR
TAD YEAR /MAY BE!

LOOP, CLL
TAD M400
SNL
JMP N400V
SZA
JMP LOOP
JMP NLY-1 /YEAR=MULTIPLE 400
N400V, TAD C100 /LEAPYEAR
SPA
JMP N400V
SZA CLA
CLA CMA
NLY, TAD M28 /SET FEB TO 28 OR 29 DAYS
DCA MONLST+2
JMP EXIT

/
DECIMAL
MONLST, MONLST
-31
-28
-31
-30
-31
-30
-31
-31
-30
-31
-30
-31
-30
-31

/
MIN, 0
HOUR, 0
DAY, 0
DAYW, 0 /DAY OF THE WEEK, OPTIONAL!
MONTH, 0
YEAR, 1973
/

```

/GENERAL CONSTANTS

/  
M50, -50  
M60, -60  
M24, -24  
M28, -28  
M12, -12  
M400, -400  
C100, 100  
OCTAL  
C7, 7  
C3, 3  
TICK, 0  
SEC, 0

/GENERAL INTERRUPT RETURN

/  
EXIT, CLA CLL  
TAD LINK  
RAR  
TAD ACCU  
ION  
JMP I 0

/  
TEMP, 0  
ACCU, 0



LINK, 0

075

/PRINT DATE, WEEKDAY AND TIME FROM THE REGISTERS:

/ MIN /0-59  
/ HOUR /0-23  
/ DAY /1-31  
/ DAYW /1-7  
/ MONTH /1-12  
/ YEAR

/USING THE SUBROUTINES:

/ PRMMSG /PRINT MESSAGE  
/ DPRT1 /DECIMAL PRINT  
/ PRINT /STANDARD PRINT ROUTINE

PRDAT, 0

TAD LAYW  
TAD DTXTAD  
DCA PRTMP  
TAD I PRIMP  
DCA PRDAT1  
JMS PRMMSG

PRDAT1, 0

JMS SPAC  
TAD DAY  
JMS DPRT1  
2  
JMS SPAC  
TAD MONTH  
TAD MTXTAD  
DCA PRTMP  
TAD I PRIMP  
DCA PRDAT2  
JMS PRMMSG

PRDAT2, 0

JMS SPAC  
TAD YEAR  
JMS DPRT1  
4  
JMS SPAC  
TAD HOUR  
JMS DPRT1  
2  
TAD DOT  
JMS PRINT  
TAD MIN  
JMS DPRT1  
2  
JMP I PRDAT

/  
PRIMP= .

SPAC, 0

TAD C240  
JMS PRINT  
JMP I SPAC

/  
DOT, ".  
C240, 240

/  
/

DTXTAD, DTXTAD

SUN  
MON  
TUES  
WED  
THUR  
FRI  
SAT

/

MTXTAD, MTXTAD

JAN  
FEB  
MAR  
APR  
MAY  
JUN  
JUL  
AUG  
SEP  
OCT  
NOV  
DEC

/

JAN, TEXT "JANUARY "  
FEB, TEXT "FEBRUARY "  
MAR, TEXT "MARCH "  
APR, TEXT "APRIL "  
MAY, TEXT "MAY "  
JUN, TEXT "JUNE "  
JUL, TEXT "JULY "  
AUG, TEXT "AUGUST "  
SEP, TEXT "SEPTEMBER"  
OCT, TEXT "OCTOBER "  
NOV, TEXT "NOVEMBER "  
DEC, TEXT "DECEMBER "

/

PAGE

/

MON, TEXT "MONDAY "  
TUES, TEXT "TUESDAY "  
WED, TEXT "WEDNESDAY"  
THUR, TEXT "THURSDAY "  
FRI, TEXT "FRIDAY "  
SAT, TEXT "SATURDAY "  
SUN, TEXT "SUNDAY "

/

```

/SUBROUTINE TO UNPACK TSS-8 TIME
/
/CALL: JMS UNPTIM /WITH AC=0
/
/RESULT IN REGISTERS:
/          HOUR   /0-23
/          MIN    /0-59
/          SEC    /0-59
/
/THIS ROUTINE ASSUMES THAT THE SYSTEM CLOCK RATE
/IS 20 SYSTEM TICKS PER SECOND,
/IF OTHER, CHANGE CONSTANTS AT UNPTHI UP TO UNPTLO+2
/
/
UNPTIM,0
      TAD UNPTAD
      TOD                /GET TIME OF DAY
      TAD UNPTHA
      DCA UNPTPH         /SET POINTERS
      TAD UNPTLA
      DCA UNPTPL
      TAD UNPTOT
      DCA UNPTPO
      CLA CLL CMA RTL   /-3
      DCA UNPTCT
UNPTLP,DCA UNPTNM      /CLEAR NUMBER
      TAD UNPTL
      CLL
      TAD I UNPTPL
      DCA UNPTMP
      RAL
      TAD UNPTH
      TAD I UNPTPH
      SNL
      JMP UNPTND
      DCA UNPTH         /RESTORE HIGH REMAINDER
      TAD UNPTMP
      DCA UNPTL        /RESTORE LOW REMAINDER
      ISZ UNPTNM       /COUNT THIS SUBTRACTION
      JMP UNPTLP+1
UNPTND,CLA
      TAD UNPTNM       /GET NUMBER
      DCA I UNPTPO     /PUT IN SPEC. REGISTER
      ISZ UNPTPH       /UPDATE POINTERS
      ISZ UNPTPL
      ISZ UNPTPO
      ISZ UNPTCT       /READY?
      JMP UNPTLP       /NO, LOOP
      JMP I UNPTIM     /YES, EXIT
/

```

UNPTAL, UNPTH  
 UNPTH, 0  
 UNPTL, 0  
 UNPTNM, 0  
 UNPTCT, 0  
 UNPTMP, 0  
 UNPTPO, 0  
 UNPTOT, HOUR  
           MIN  
           SEC  
 UNPTPL, 0  
 UNPTPH, 0  
 UNPTHA, UNPTHI  
 UNPTLA, UNPTLO  
 UNPTHI, 7756  
           7777  
           7777  
 UNPTLO, 3300  
           5520  
           7754  
 /  
 HOUR, 0  
 MIN, 0  
 SEC, 0

/LOW ORDER POINTER  
 /HI ORDER POINTER  
 /ADDR. OF HI ORDER CONSTANTS  
 /ADDR. OF LOW ORDER CONSTANTS  
 /-# OF TICKS/HOUR=-72000 DEC.  
 /-# OF TICKS/MIN =- 1200 DEC.  
 /-# OF TICKS/SEC =- 20 DEC.

```

/SUBROUTINE TO UNPACK TSS-8 TIME
/
/CALL: JMS UNPTIM /WITH AC=0
/
/RESULT IN REGISTERS:
/          HOUR   /0-23
/          MIN    /0-59
/          SEC    /0-59
/
/THIS ROUTINE WORKS FOR ANY CLOCKRATE
/
UNPTIM,0
    FCR
    CIA
    DCA UNPTDV           /PUT IN DIVISOR LIST
    TAD UNPTAD
    TOD                 /GET TIME OF DAY
    TAD UNPTDA
    DCA UNPTPD
    TAD UNPTOT
    DCA UNPTPO
    TAD M4
    DCA UNPTCT
UNPTLP, DCA UNPTNM       /CLEAR NUMBER
    DCA UNPTNM+1
    TAD UNPTL
    CLL
    TAD I UNPTPD
    DCA UNPTMP
    SNL
    CLA CMA
    TAD UNPTH
    SNL
    JMP UNPTND
    DCA UNPTH           /RESTORE HIGH REMAINDER
    TAD UNPTMP
    DCA UNPTL         /RESTORE LOW REMAINDER
    ISZ UNPTNM        /COUNT THIS SUBTRACTION
    SKP
    ISZ UNPTNM+1      /HI ORDER RESULT
    JMP UNPTLP+2
UNPTND, CLA
    TAD UNPTNM+1
    DCA UNPTH
    TAD UNPTNM        /GET NUMBER
    DCA I UNPTPO      /PUT IN SPEC. REGISTER
    ISZ UNPTFD        /UPDATE POINTERS
    ISZ UNPTPO
    ISZ UNPTCT        /READY?
    JMP UNPTLP        /NO, LOOP
    JMP I UNPTIM      /YES, EXIT
/

```

UNPTAL, UNPTH  
UNPTNM, 0  
0

/LOW ORDER  
/HIGH ORDER

UNPTCT, 0  
UNPTMP, 0  
UNPTPO, 0  
UNPTOT, UNPTL  
HOUR  
MIN  
SEC

UNPTPD, 0  
UNPTDA, UNPTDV

/POINTER IN DIV LIST

/  
DECIMAL

/  
UNPTDV, 0  
-3600  
-60  
-1

/  
OCTAL

/  
UNPTH, 0  
UNPTL, 0  
HOUR, 0  
MIN, 0  
SEC, 0

/  
M4, -4

078

```

/SUBROUTINE TO UNPACK 1558 DATE
/
/RESULT IN REGISTERS
/      DAY      /1-7
/      MONTH    /1-12
/      YEAR     /ANY
/
UNPDAT,0
      DATE          /GET DATE FROM TS8
      DCA DAY
      JMS DATDIV   /DEVIDE BY
      -564         /564(SUBTRACT)
      TAD TIMES
      TAD C1964    /AC=YEAR-1964 (DEC)
      DCA YEAR
      JMS DATDIV   /DEVIDE REST BY 37
      -37
      ISZ TIMES    /MONTHS MUST BE +1
      TAD TIMES
      DCA MONTH
      ISZ DAY      /REMINDER IS DAYS-1
      JMP I UNPDAT
/
/SUBROUTINE DATDIV DEVIDES 'DAY' BY GIVEN NUMBER
/
DATDIV,0
      DCA TIMES    /CLEAR RESULT
DATD1, CLL
      TAD DAY      /NUMBER TO DEVIDE
      TAD I DATDIV /NUMBER TO DEVIDE BY
      SNL         /READY?
      JMP DATD2    /YES
      DCA DAY      /NO STORE REST
      ISZ TIMES    /COUNT SUBTRACTION
      JMP DATD1    /SUBTRACT ONE'S MORE
DATD2, CLA CLL    /REST IS IN NUMB
      ISZ DATDIV
      JMP I DATDIV /EXIT
/
TIMES, 0
C260, 260
LAY, 0
MONTH, 0
YEAR, 0
/
      DECIMAL
C1964, 1964
      OCTAL

```

Ø79

```

/DECIMAL PRINT WITH VARIABLE NUMBER OF DIGITS
/
/CALL WITH NUMBER TO BE PRINTED IN AC
/AND # OF DIGITS TO BE PRINTED
/FOLLOWING THE SUBROUTINE CALL.
/
/CALL: TAD NUMBER
/      JMS DPRT1
/      2          /# OF DIGITS TO BE PRINTED (MAX=4)
/
/
DPRT1, 0
      DCA DPRREG          /SAVE AC
      DCA DPRD           /CLEAR # OF PRINTED DIGITS
      TAD I DPRT1        /FETCH FORMAT
      DCA DPRDIG
      ISZ DPRT1          /CORRECT RETURN
      TAD DPRINS
      DCA DPRPTR         /SET POINTER
      CLA CLL CMA RTL    /-3
      DCA DPRFAC         /FACTORIZE 4 DIGITS
      DCA DPRDGT         /CLEAR DIGIT
DPRSUB, CLL
      TAD DPRREG
DPRPTR, 0
      SNL                /SUBTRACT
      JMP .+4            /NEGATIVE?
      DCA DPRREG         /YES
      DCA DPRREG         /STORE RESULT OF SUBTRACTION
      ISZ DPRDGT        /NO, STEP UP DIGIT
      JMP DPRSUB
      CLA
      TAD DPRDGT         /GET DIGIT
      TAD DPRD
      SZA CLA            /PRINT THE DIGIT?
      JMP DPRDIN         /YES, GO ON
      TAD DPRFAC         /NO,
      TAD DPRDIG
      SPA SNA CLA        /PRINT A SPACE?
      JMP DPRTIN         /NO
      TAD C240           /YES
      JMP DPRPR
DPRDIN, ISZ DPRD
      TAD DPRDGT         /FETCH DIGIT
      TAD C260           /CONVERT TO ASCII
DPRPR, JMS PRINT
DPRTIN, ISZ DPRPTR       /STEP UP POINTER
      ISZ DPRFAC
      JMP DPRSUB-1
      TAD DPRREG         /FETCH LAST DIGIT
      TAD C260
      JMS PRINT
      JMP I DPRT1
/

```



DPRREG,0  
DPRD, 0  
DPRDIG,0  
DPRFAC,0  
DPRDGT,0  
DPRINS,TAD DPRP

/

DECIMAL

/

DPRP, -1000  
-100  
-10

/

OCIAL

/

GENERAL CONSTANTS

/

C260, 260  
C240, 240

Ø8Ø

/ OCTAL PRINT ROUTINE WITH LEADING SPACES  
/NONSIGNIFICANT ZERO'S BECOME SPACES  
/LINK NEEDS NOT TO BE PRESERVED BY 'PRINT' ROUTINE.

/  
/CALL: TAD NUMBER  
/ JMS OCTPRT  
/  
/ RETURNS WITH AC=Ø  
/

OCTPRT, Ø .  
DCA OCTTMP  
TAD M4  
DCA OCTCNT  
CMA

OCTPRØ, DCA OCTFIG  
TAD OCTTMP  
RAL  
RTL  
DCA OCTTMP  
TAD OCTTMP  
RAL  
AND C7  
ISZ OCTCNT  
JMP .+4  
TAD C26Ø  
JMS PRINT  
JMP I OCTPRT

SNA  
ISZ OCTFIG  
JMP .+4  
TAD C24Ø  
JMS PRINT  
JMP OCTPRØ-1

TAD C26Ø  
JMS PRINT  
JMP OCTPRØ

OCTTMP, Ø  
OCTCNT, Ø  
OCTFIG, Ø  
M4, -4  
C7, 7  
C24Ø, 24Ø  
C26Ø, 26Ø

/ DOUBLE WORD OCTAL PRINT ROUTINE

/  
/CALL: JMS DOCTPR  
/ HIORDER PART  
/ LOWORDERPART  
/ RETURN AC=0  
/

DOCTPR, 0  
CLA  
TAD I DOCTPR  
ISZ DOCTPR  
DCA OCTTM1  
TAD I DOCTPR  
ISZ DOCTPR  
DCA OCTTM2  
TAD M10  
DCA OCTCNT  
CMA

OCTPR1, DCA OCTFIG  
JMS DELROT  
JMS DELROT  
JMS DELROT  
TAD OCTTM2  
HAL  
AND C7  
ISZ OCTCNT  
JMP .+4  
TAD C260  
JMS PRINT  
JMP I DOCTPR

SNA  
ISZ OCTFIG  
JMP .+4  
TAD C240  
JMS PRINT  
JMP OCTPR1-1

TAD C260  
JMS PRINT  
JMP OCTPR1

OCTTM1, 0  
OCTTM2, 0  
OCTCNT, 0  
OCTFIG, 0  
M10, -10  
C7, 7  
C240, 240  
C260, 260

DELROT, 0  
TAD OCTTM2  
HAL  
DCA OCTTM2  
TAD OCTTM1  
HAL  
DCA OCTTM1  
JMP I DELROT

/ASCII STRING GENERATOR

/GENERATES THE 64-CHARACTER ASCII SET IN A STRING

/TERMINATED WITH CARRIAGE RETURN, LINE FEED

/

/CALL: CLA

/ JMS GENSTR

/ RETURN (AC=0)

0 /END OF PARTIAL STRING

0 /POINTER

0 /TEMPORARY STORAGE

GENSTR, .-. .

TAD GENLST

DCA GENSTR-2 /INITIALIZE POINTER

TAD GENSTR-2

TAD GENLTH

DCA GENSTR-1

TAD I GENSTR-1 /GET NEXT CHARACTER

DCA GENSTR-1

ISZ GENSTR-2 /INCREMENT POINTER

TAD I GENSTR-2

SNA /END OF LIST ?

JMP I GENSTR /YES

CIA

DCA GENSTR-3 /SET UP TO TEST

GENLP, TAD GENSTR-1

JMS PRINT

ISZ GENSTR-1 /CHARACTER +1

TAD GENSTR-1

TAD GENSTR-3

SPA SNA CLA /EQUAL TO POINTED CHARACTER ?

JMP GENLP

JMP GENSTR+3 /YES, GET NEXT CHARACTER

GENLTH, GENNXT-GENLST

GENLST, .

332 /Z

271 /9

257 /SLASH

300 /@

337 /←

215 /RETURN

212 /LINE FEED

0 /TERMINATOR

GENNXT, 301 /A

260 /0

240 /SPACE

272 /:

333 /C

215 /RETURN

212 /LINE FEED

```

/INCREMENT DOUBLE PRECISION COUNTER
/WITH OVERFLOW RETURN (AFTER 16,777,216 INCREMENTS)
/
/CALL:   JMS      DPINC
/        DPCNTR  /ADDRESS OF COUNTER
/        COUNTER OVERFLOWED RETURN (AC=0)
/        NORMAL RETURN (AC=0)
/
/        DPCNTR, 0          /HIGH ORDER PART
/        0          /LOW ORDER PART

DPINC,   0          /TEMPORARY ADDRESS
        .-.
        CLA CLL IAC      /SET UP TO GET ADDRESS OF
        TAD I   DPINC    / LOW ORDER PART
        DCA     DPINC-1
        ISZ I   DPINC-1
        JMP     DPINC1   /NO OVERFLOW
        CML
        SZL
        JMP     DPINC+2 /INCREMENT HIGH ORDER PART
        SKP     /HIGH ORDER PART OVERFLOW
DPINC1,  ISZ     DPINC
        ISZ     DPINC
        JMP I   DPINC

```

